






DO NOT PRINT "PRINTER SLUG" LAYER!

Brookstone®		PRINTER SLUG FOR MANUAL PRINTING	
CATEGORY: DESCRIPTION: Indoor Dual WIFI Plug FILE NAME: BR-PL-WF-003-WT REV.3 Manual & Quick Start		ADDITIONAL PRINTING PROCESSES: SPOT UV COAT FINISH: VARNISHING TECHNIQUE: MATTE VARNISHING OVER THE ENTIRE BOX	
PRESS WORK: TRIM TO SIZE, SCORE & FOLD WHEN SPECIFIED SCALE: 100% DIELINE OVERALL DIMENSIONS (in Millimeters) WIDTH: HEIGHT:		PRESS SPEC COLOR REFERENCES <div><div> DIELINE</div><div> SPOT UV GLOSS</div><div> EMBOSSING (RELIEF)</div><div> DEBOSSING (SUNKEN)</div><div> FOLDING LINE</div></div>	
PRINTING MATERIALS & THICKNESS & SIZE SUBSTRATE TYPE: ART PAPER SBS C2S 80gsm Minimum Brightness of 85% White!			
PRINTING TYPE: 4/4 PRINT, TRIPLE PARALLEL FOLD		ADDITIONAL PANTONE COLORS (NOT CMYK) SOLID COLOR NAME: NEON COLOR NAME: METALLIC COLORS:	
APPROVAL CHECKLIST: PRIMARY DESIGNER: IOSIF DATE: 05.07, 05.29.2024, 06.24.24, 09.23.24 SECONDARY DESIGNER: DATE: PROOF READ: DATE: APPROVED BY: DATE: AUTHORIZATION SIGNATURES:		FILE SAVED AS: .ai = FULLY EDITABLE -.OL.ai = OUTLINED .pdf = Acrobat .jpg = Flat image	

**SCORE AND FOLD AS SHOWN
ON THIS PICTURE**



QUICK START GUIDE OUTSIDE PAGES

Brookstone

Wi-Fi Dual Smart Plug

15A Power Rating

That's It! It's Simple!

Brookstone

©2024 BYTECH NY INC, Brooklyn, NY 11223.
 The BROOKSTONE® trademarks, names and logos are owned by BKST Brand Holdings LLC.
 ©2024, All rights reserved.
 Manufactured, marketed and distributed by Bytech NY INC., under license, Made in Vietnam.

Alexa® is a registered trademark of Amazon, Inc., Google Play® and Google Assistant are registered trademarks of Google, Inc.
 App Store® is a registered trademark of Apple, Inc. Wi-Fi™ is a trademark of Wi-Fi Alliance®.

All trademarks and registered trademarks are property of their respective owners.

Customer service contact information:
 2585 West 13th Street, Brooklyn, NY 11223
 (718) 449-3700 www.bytechnl.com

QUICK START GUIDE

QUICK START GUIDE INSIDE PAGES

QUICK START GUIDE

AS EASY AS 1-2-3

- # 1.

Insert the Dual Smart Plug into the power outlet.
- # 2.

Download and Install the Brookstone App.

SCAN QR CODE OR VISIT:

<https://brookstonesmarthome.com/indoor-15a-dual-outlet-smart-plug>
- # 3.

Open the App and add the Wi-Fi Dual Smart Plug.

INSTRUCTION MANUAL GUIDE OUTSIDE PAGES

Screenshot 1: Schedule Page

1. Countdown. Set a timer.
2. Schedule page is activated (highlighted icon). You are able to program day & time to turn it ON/OFF.
3. Random. Create a random schedule for the Dual Smart Plug to turn it On/Off.
4. Astronomical. Sunrise & sunset settings.
5. Add new Schedule.

Screenshot 2: Add Schedule Page

1. Time setting.
2. Date setting.
3. Dual Smart Plug notification & activation.
4. Saving a new schedule.

Screenshot 3: Create Scene Page

1. Launch Tap-to-Run. Example: turn off all lights in the bedroom with one tap.
2. When weather changes. Example: when local temperature is greater than 30°C.
3. Schedule. Example: 7:00 a.m. every morning.
4. When device status changes. Example: when an unusual activity is detected.

Screenshot 4: Me Page

1. Edit your picture & name.
2. Additional settings & updates.
3. Alexa & Google Assistant connection settings.
4. Save your address location for weather & time settings.
5. Notifications on app's status & conditions.
6. Frequently Asked Questions.
7. Home Page.
8. Open Scene setting page.
9. Me setting page is activated (highlighted icon).

Screenshot 5: Setting Page

1. Run Log. Shows you the log of your device.
2. Light Mode. Control how the LED light on your device operates.
3. Relay Status. Recognize the current status of the switch & allows you to schedule the alternative action.

Screenshot 6: Run Log

1. Run Log. Shows you the log of your device.
2. Light Mode. Control how the LED light on your device operates.
3. Relay Status. Recognize the current status of the switch & allows you to schedule the alternative action.

Screenshot 7: Light Mode

1. Run Log. Shows you the log of your device.
2. Light Mode. Control how the LED light on your device operates.
3. Relay Status. Recognize the current status of the switch & allows you to schedule the alternative action.

Screenshot 8: Relay Status

1. Run Log. Shows you the log of your device.
2. Light Mode. Control how the LED light on your device operates.
3. Relay Status. Recognize the current status of the switch & allows you to schedule the alternative action.

Screenshot 9: Me Page

1. Edit your picture & name.
2. Additional settings & updates.
3. Alexa & Google Assistant connection settings.
4. Save your address location for weather & time settings.
5. Notifications on app's status & conditions.
6. Frequently Asked Questions.
7. Home Page.
8. Open Scene setting page.
9. Me setting page is activated (highlighted icon).

Screenshot 10: Me Page

1. Edit your picture & name.
2. Additional settings & updates.
3. Alexa & Google Assistant connection settings.
4. Save your address location for weather & time settings.
5. Notifications on app's status & conditions.
6. Frequently Asked Questions.
7. Home Page.
8. Open Scene setting page.
9. Me setting page is activated (highlighted icon).

Screenshot 11: Me Page

1. Edit your picture & name.
2. Additional settings & updates.
3. Alexa & Google Assistant connection settings.
4. Save your address location for weather & time settings.
5. Notifications on app's status & conditions.
6. Frequently Asked Questions.
7. Home Page.
8. Open Scene setting page.
9. Me setting page is activated (highlighted icon).

INSTRUCTION MANUAL GUIDE INSIDE PAGES

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Key Features

- The Wi-Fi Dual Smart Plug makes it easy to independent control "non-smart" devices in your home
- Allows you to turn numerous wired appliances in your home into automated units that can be controlled by simple taps on your phone, or voice commands via Google and Amazon,
- Easy to install and set-up
- Independent schedule ON/OFF time for home automation
- Output Voltage: 15A Max, 1250W Tungsten, ½ HP
- Wi-Fi Standard 802.11 b/g/n
- Wi-Fi Channel 1-14 @ 2.4GHz
- Works with the Brookstone App
- Works with your Apple®, Google, and Amazon® devices
- App available on iOS and Android

Package Contents

- Wi-Fi Dual Smart Plug
- Instruction Manual
- Quick Start Guide

Safety Instructions

- Keep the Dual Smart Plug away from extreme heat sources or fire.
- Do not use the Dual Smart Plug if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the Dual Smart Plug free from dust, lint, etc.
- Do not use this Dual Smart Plug for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy

Compatibility

This Wi-Fi Dual Smart Plug is compatible with the Brookstone App® and with the devices using iOS 8.0 and above with Wi-Fi option, or Android 5.0 and above with Wi-Fi option.

This device does not currently support 5GHz Wi-Fi bands. Please see that your phone is connected to 2.4GHz Wi-Fi band of your router.

Operating Instructions

Search and download Brookstone App from Apple App Store® or Google Play®, or SCAN QR CODE, or VISIT: <https://brookstonemarthome.com/instore-tbe-dual-outlet-smart-plug>

Open the App, and it will ask you to register your device.

Select your country, enter your email, get Verification Code and input your password to confirm. Insert the Dual Smart Plug into the power outlet. Wait for 10-30 seconds until the Blue LED light blinks continuously.

Wi-Fi Dual Smart Plug parts and description

- Dual Smart Plug grounded receptacles
- ON/OFF Switch
- LED Illuminated indicators

Troubleshooting Dual Smart Plug connection:

In the event that the Dual Smart Plug does not automatically connect, please check that your phone is turned on and you gave permission for the App to access the Wi-Fi.

Make sure the Dual Smart Plug LED indicator is flashing. If the Wi-Fi signal is not flashing, you will need to press and hold ON/OFF Switch. Make sure the Wi-Fi network is a 2.4GHz network, the device will not connect to a 5Ghz network.

Test your Wi-Fi network connection with other devices such as your phone or computer to make sure it is operated properly. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection. Your Wi-Fi network password is case sensitive, make sure you are entering it correctly.

There could be a temporary issue with your Internet connection (e.g., service disruption). Please try again in a few minutes.

Make sure your Bluetooth and Wi-Fi router is turned ON. The Dual Smart Plug may not have power, make sure the wall switch and breaker is in the ON position. Make sure the Dual Smart Plug is getting a good signal from your Wi-Fi router.

App Main Functions

- Location management.
- Add a new device.
- Location weather information.
- Display management.
- Me. Your personal information: Home Management, FAQ & Feedback.
- Smart scene with conditions of other smart devices.
- Home device list.

Edit or change product name.

Manually switch both outlets On/Off.

Individually select the outlet you want to turn On/Off.

Timer and Scheduling for each Individual Outlet.

Settings