


# USB Wireless Adapter Quick Installation Guide

Note: This Manual based on Windows7


01. Put in the CD and find windows file "windows (xp,vista,win7,win8,win10)" and Setup.exe.



02. Double click Setup.exe file, Software begin to initialization, then click the "Next". There shows the installation progress.




REALTEK USB Wireless LAN Driver and Utility  
Setup Status



03. Do not interrupt installation, Click "Finish" to finish the driver installation. The computer automatically restart.



REALTEK USB Wireless LAN Driver and Utility  
InstallShield Wizard Complete




04. Plug the Wireless USB Adapter into the USB port of your PC



Wireless connection (two ways to realize Wireless connection 1):



05. Click Icon in the Windows system tray, which locates in the bottom-right corner of your computer screen or double click , and pops up a message and click "Available Network" Double-click the utility icon or right click the icon , and the Wireless Network Connection window appears then double click the SSID you preferred.




Type the encryption key that you wrote down earlier in both the Network key and Confirm network key boxes, and then click "ok".




pictures shows: Wireless Connection2.

06. Click Icon which locates in the bottom-right corner of your computer screen, click the wireless network list and choose the SSID you preferred, and double click (Or click "Connect").

Note: if there is no icon , please find it in the on right bottom, it have been hide as following



Type the encryption key and then click "ok".



Type the encryption key and then click "ok".

## FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**RF Exposure Information**  
SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

Before a new device is available for sale to the public, it must be tested and certified to the FCC that does not exceed the exposure limit established by the FCC. Tests for each device are performed in positions and locations as required by the FCC. For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designed for this product or when used with an accessory that contains no metal and that positions a minimum of 5mm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.