

INSTRUCTION MANUAL

BLUETOOTH HEADPHONE

EY13B



DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.


NOTE

This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

Specification

Model	EY13B	Type	Headset
Protocol	A2DP,AVRCP,HSP	Charge port	USB
Frequency	20Hz-20KHz -/+3dB	Effective Range	<10 Meter
Sensitivity	105±3 dB	Specification	Φ10mm
Music time	Up to 8 hours	Talk time	Up to 9 hours
Standby time	Up to 120 hours	Charge Voltage	5V
Microphone	Support	Charge Current	80mA

Switch/Button/Port



1. Charging the battery with Micro USB cable

Insert USB charging cable into USB port which have support 5V power(such as AC/DC USB adapter or PC USB port)

Connect charging cable to the charging port of headset.

- When the red light is on, the headset is in charging.
- When the blue light is on, the headset is fully charged.
- It takes around 1-2 hours to charge the headset fully.

2. Turn on the Headset

Press and hold the MFB button for 3 seconds until the LED indicator flash blue.

3. Turn off the Headset

Press and hold the MFB button for 5 seconds until the LED indicator flash red.

4. Paring your Headset

Please make sure your mobile phone has Bluetooth function that can be used.

Please keep the headset and mobile phone in the range of 1 meter when pairing.

Press and hold the MFB button for 5 seconds until the LED indicator flash red and blue alternately.

After searched, select "EY13B" in the Bluetooth device list

According to indication, enter password or PIN NO. "0000", and press the key of "YES" or "Confirmed".(It depends on the Bluetooth device setting)

After connect successfully, the blue LED of the headset will keep blinking.

5. Answering/Rejecting/Ending a call

Press the MFB button once to answer the incoming call; Press and hold the MFB button for 3 seconds to reject the incoming call; Press the MFB once to end the call.

6. Last Number Redial From Your Headset

In standby status, Press and hold the MFB button for 3 seconds to redial the last number.

7. Adjust the volume

When you are on phone or listening to the music, press and hold the volume button until you reach the desired volume level.

8. Last/Next Track

While the music playing, press the "Last Track" key or "Next Track" key to select the songs.

9. Play/Pause Music

While music playing, press the MFB button once to pause, and press the button once again to continue to play.

10. Maintenance

1. Turn off your headset;
2. Please keep the environment temperature between 0~45 degree centigrade.
3. Please keep the headphone away from rain、water, or any other liquid.
4. you should charge your headset once a month at least.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value for human head and body. Therefore, SAR test is not necessary.