






Product Overview



Packing List


Digital Signage



Power cord



Operation manual



Warning

- ⚠ Do not use any kinds of power supply other than AC 100V, 50/60Hz or 220V, 50/60Hz.
- ⚠ Do not fix the signage in an unstable place and position, otherwise it may cause damage due to falling, or even cause fire.
- ⚠ Do not place the signage under strong and direct light, in an environment with high humidity, overheat or much dust, in an environment storing or using flammable and explosive substances, and an environment with combustible or corrosive gases.
- ⚠ Do not use damaged or unfitted power socket. Please make sure the plug fits well the power socket. The plug and power socket should not adhere to dust and metal attachment.
- ⚠ The power cord should not be damaged. Any modification of the power cord is strictly prohibited. Keep the power cord away from heat source. Do not pull the power cord when pulling off the plug.
- ⚠ Do not touch the plug with wet hands, otherwise it may cause electric shock.
- ⚠ When it rains, do not use the signage on outdoor.
- ⚠ Do not in any way disassemble the signage, or it may cause electric shock or fire. All repairs should be managed by a professional technical staff.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Specifications

Screen size :	32inch	43inch
Screen resolution :	768x1366	1080x1920
Brightness :	300cd/m ² (typical)	300cd/m ² (typical)
Contrast ratio :	1000:1	1000:1
Dimension :	1100x440x67(mm)	1300x576x67(mm)
Weight :	14.1 kg	21.7 kg
Internet connect	LAN / Wi-Fi / 4G(Optional)	LAN / Wi-Fi / 4G (Optional)
Content format		
Picture:	jpg, bmp, png, gif	
Video :	AVI, MPEG2, MPEG4, WMV	
Audio :	mp3	

Operate the signage

1. Switch on the Power



2. Content distribution

a. Use a USB drive to play back pictures and videos

Copy the pictures or videos to the USB drive under the root directory (FAT 32 format). Plug it into the USB interface. The signage will automatically playback the picture and videos in sequence of files' name.

b. External devices playback through HDMI

Connect the external device to the HDMI interface prior to switching on the signage. After switching on, the signage will automatically play back the contents from the external device.

c. Play with web players

The signage can connect to the network with cable or through Wi-Fi, and then the software meeting the Android 4.4 standard can be installed in the signage and used. For further details, please consult the software developer of the digital signage.

d. This Router does not connect to Public Network directly

3. Manual of the Rechargeable Batteries Package (Optional)


a. Users must use the manufacturer's original Package with rechargeable 24V batteries.

b. The recharging and the DC out use the same port.

c. To supply electricity to the digital signage from the batteries, please use the 24V power cord packed with the Package to connect the batteries with the 24V port on the digital signage.

d. To charge the batteries, please use the 24V charger packed with the Package.

e. Warning: It is strictly prohibited to use any 220V power cord to connect the batteries with the 220V city power.



Digital Signage

Operating Instructions