

#### FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### TROUBLESHOOTING

##### No power

Recharge your earbuds using the included Micro USB charging cable

##### Music is not playing over bluetooth

Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the earbuds to reconnect your Bluetooth device.

##### Bluetooth device will not reconnect with the earbuds

Navigate to your Bluetooth settings menu on your Bluetooth device, tap "MERCURY BTE74," and select "Forget." Now follow the steps to pair your device again.

#### Specification:

Bluetooth® Version: 4.2  
Bluetooth® Range: Up to 30ft  
Charging Voltage: 5V  
Charging Input: Micro USB  
Freq. Response: 20Hz - 20kHz

Battery Capacity: 85mAh  
Battery Time: Approx. 1.5 Hours  
Playback Time: Approx. 5 Hours  
Standby Time: Approx. 40 Hours  
\*Depends on individual use

#### Technical Support:

Please do not return the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Mercury Innovations technical support:

Mercury Innovations  
45 Broadway 3rd Fl. New York, NY 10006  
www.mercuryinnovations.com  
E-mail: support@mercuryinnovations.com

#### © 2017 Mercury Innovations LLC

To report a product defect, please visit us at: [www.mercuryinnovations.com](http://www.mercuryinnovations.com)

The Bluetooth word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.  
Made in China



User's Manual  
For LG-BT800

Included:  
UPTOWNS Wireless Earbuds  
3 Sizes of Silicone Earbuds Tips  
Micro USB Charging Cable


## UPTOWNS

## WIRELESS

### Metallic Wireless Neckrest Earbuds

IMPORTANT Please read before using this product

#### PRODUCT/CONTROLS DIAGRAM



#### CHARGE IT

- Plug the micro USB cable into the micro USB port on the side of the neck band and connect the other end of the cable to either a computer USB port or a USB-compatible charger.
- Solid red LED light will indicate when the earbuds are charging, even while they are turned off.
- When charging is complete, the LED light will turn off.
- Charging time is approximately 1.5 hours.

#### PAIR & CONNECT WITH A NEW DEVICE

- With your earbuds powered OFF, press & hold the 'J' button for 2-3 seconds until the LED light flashes red and blue. Your earbuds are ready to be paired.
- On your smartphone, open the Bluetooth settings and search for new devices.
- After a few seconds you will see "MERCURY BTE74" listed, tap it.
- The earbuds will begin to play a short tone and begin to slowly blink blue, and the earbuds will emit a tone to indicate that it has been successfully paired with your device.

NOTE: You only need to pair your Bluetooth device with the UPTOWNS earbuds once.

NOTE: If your device asks for a password to connect to the earbuds, enter "0000".

#### PLAY

- Connect your device to the UPTOWNS earbuds via Bluetooth (see "Pair & Connect with a New Device").
- Open your favorite music app and press play.
- Control the track & volume from your device, or using the inline controls on the UPTOWNS earbuds. Press the 'J' button once to play/pause music & answer calls.
- After the '++' or '--' button once raise/lower the volume on the earbuds. Press and hold to skip to the next/previous track.
- All audio, including music, games, videos, and notifications will be routed through the UPTOWNS earbuds.

#### RECONNECT WITH YOUR DEVICE

- Press & hold for 2-3 seconds on the UPTOWNS earbuds for 2-3 seconds.
- The earbuds will power on and the LED light will flash, and will automatically reconnect to the last Bluetooth device they were connected to.
- If you haven't paired the earbuds to any device follow the steps in the "Pair & Connect" section.
- If the earbuds don't auto-reconnect to your device, navigate to the Bluetooth menu and tap "MERCURY BTE74".

#### POWER ON/OFF

- Press and hold the 'J' button for 2-3 seconds to power on.
- The LED light will flash blue.
- Press and hold the 'J' button for 2-3 seconds to power off.

