

正面

54.00

111.00

USER MANUAL



ekster.com/usermanual

Scan the QR code for our user manual, or visit [ekster.com/usermanual](https://ekster.com/usermanual).

OUR STORY

Here at Ekster, we make better gear for life on the go.

Everything we do centers around the desire to get the most out of every single day. We aim to leave the biggest impact on how you move through the world with the smallest impact on the world itself.

GET STARTED

**1 Activate your Finder Tag**


Press the button on the back of the Finder Tag until you hear a sound.

**2 Pair with your iPhone®**

Open the Apple® Find My® app. Tap on 'Items', select 'Add an item' then 'Add Other Item'. Follow the on-screen instructions until your Finder Tag is visible.

**3 Use Find My**

Locate your Finder Tag easily by ringing it or locating it on a map. In the Apple Find My app, go to 'Items', select the Finder Tag, and tap 'Play Sound'.



IC Caution

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS (standard(s)). Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

French:

Cet appareil est conforme aux normes RSS exemptées de licence d'innovation, sciences et développement économique Canada. L'exploitation est soumise aux deux conditions suivantes:

(1) L'appareil ne doit pas produire de brouillage, et

(2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'empêcher ses fonctionnements.

Le matériel a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences. Le dispositif peut être utilisé dans des conditions d'exposition.

背面

54.00

111.00

STEP 1  
GRAB THE TOOL

Use the metal tool below, or another thin object like a flathead screwdriver.



STEP 2  
INSERT THE TOOL

Press the tool into the small slit on the bottom of the Finder Tag until it hits the bottom.



STEP 3  
OPEN THE COVER

Push the tool toward the button on the Finder Tag to open the cover. You should hear a click when it opens.



STEP 4  
CHANGE THE BATTERIES

You can now remove the cover with your hands and change the coin-cell batteries.



FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.