S29

Multifunction Bluetooth Remote Control Manual

**Video/Ebook/Selfie**

For ios/Android/Hongmeng system

Product Introduction

The video/reading remote control supports sho ort videos(Tik Tok Kuai shou, Weishi,etc.)and the page-turning function of individual mobile phone reading APPs,supports adjusting the volume of the mobile phone to increase or decrease , and truly releases both hands! It is also aselfie remote controlwhen watching short videos take a beautiful selfie!

Specifications

Support system:ios15/Android 8.0 Above/Hongmeng system
Bluetooth Version:5.3   Transmission Frenuency：2.4-2.4835Ghz
Voltage:3.9-4.2V(polymer lithium battery)
Battery：55mAh   Working Time：72 Hours
rated power:3.7V+50A   In put Voltage：DC-5V

Key Function Description

❶ Click: Page Up
Long press: increase volume

❷ Click: Flip Left
Long press: Previous track

❺ Long press: switch on/off
Click: Pause
Triple click: Cursor mode operation

❹ Click: Right Page Flip
Long press: Next song

❸ Click: Page Down
Long press: reduce volume

❻ Click: Take a photo/shoot

Charging port

❼ Double click: Like
Long press: switch to like

❽ Click: Main page
Long press: lock screen

Android/Hongmeng mobile phones can be used after pairing , the mouse or dot is not on shot button,Press the key to refer to the settings.

Note: If this product cannot be used due to iOS system upgrade, it is force majeure.

Instructions for use

Press and hold the 1 key for 3 seconds to turn on the phone. When the blue indicator light flashes, search for: Bluetooth device name After successful pairing of S29 and mobile phone Bluetooth, enter the short video APP.

**iOS15.0 Version and above can only be used after setting.**
The settings are as follows: Settings → Auxiliary Functions → Touch → Auxiliary Touch -- On → Center,The dot appears.

The setting method is below：

Tik Tok record the video as follows:
Triple-click the1 button to light up,enter the adjustment mode, click the 2 button to move the point up. click the3 button to move the point down . click the 4 button to move the point to the left . click Move the 5 key to the right, move to the recording point click the 1 key to confirm the video recording and click the 1key to complete the recording. In memory mode. next time you use the triple-click1 button the indicator light will be on enter the video recording and click the I button to start recording After completion 3 clicks 1 button, the display light turns off and exits the Tik Tok recording video mode.
If the user feels that the sensitivity of the remote controlis poor or strong.You can adjust the Tracking Sensitivity] under Execute Touch Gesture to asatisfactory sensitvity，[Exeute Touch Gesture] must be turned on, as shown in the figure below

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: –– Reorient or relocate the receiving antenna. –– Increase the separation between the equipment and receiver. –– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. –– Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction