



OPERATING INSTRUCTIONS

- 1 Download the app in the App Store or in the Google Play Store under "intAct Battery-Guard".
- 2 Attach Battery-Guard to the battery terminals (black = negative, red = positive); if necessary, fix the transmitter to the clean battery with the adhesive film provided.
- 3 Activate Bluetooth on your smartphone and then open the app. After successful connection, the battery appears in the listing and the charge status is already indicated by a coloured dot.
- 4 Selecting the battery will display the exact voltage.
- 5 The  "Pencil" icon allows the name to be changed and the nominal voltage (12V) or automatic function to be selected.
- 6 You can switch between transmitters by selecting the  "Menu" icon. Up to five batteries can be monitored.
- 7 Up to 5 values can be stored per transmitter by clicking the  "Save" icon; the oldest value will then be automatically deleted.

If the battery is not displayed, click the  "Refresh" icon or check whether Bluetooth is enabled on your smartphone.



= Pencil



= Menu



= Save



= Refresh

Note: This device is car use only!

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Stefan Keckeisen Akkumulatoren e.K may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

INDUSTRY CANADA STATEMENTS

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.