

Printing: Balck and white

* Smart phone OS update or change in the future might lead to incompatible

ON&Shot

LED

FRONT

Hanger

Battery Cover

BACK

Model NO.	"Shutter Ball"
Communication	Bluetooth 3.0
Transmit Frequency	ISM Band 2.4GHz
Active Range	10m(30ft)
Battery Life	Longer than 3-years battery life with CR2032x1 cell
Weight	About 12g



1
STEP
Pairing

2
STEP
Open App

3
STEP
shooting

- a. Press the ON/Shot button to power on the shutter ball in the power off state, if the shutter ball has not paired, the shutter will enter into pairing mode and indicator LED starts flash at same time.
- b. Active the Bluetooth function on your phone and search the device
- c. Select the device of "Shutter Ball" from the list and pair will be finished in few seconds.

Use your smartphone own camera APP to take photos via shutter ball or you can download the APP of "camera360" from Google play if built-in camera APP of your smartphone can not support, check the compatible device and APP in following instruction.



3. shooting

Select the appropriate APP and press ON/shot button to take photos.

Compatible with IOS 6.0 or newer and
Android 4.22 OS or newer

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

- - Consult the dealer or an experienced radio/TV technician for help.