

# TetraPond®

## TetraPond Triple Light Set Instruction Manual

ITEM #: 19763-00

### IMPORTANT SAFETY INSTRUCTIONS

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS
2. DANGER – To avoid possible electric shock, special care should be taken since water is employed in the use of pond equipment. For each of the following situations, do not attempt repairs by yourself; return the appliance to an authorized service facility for service or discard the appliance:
  - a. If the appliance shows any sign of abnormal water leakage, immediately unplug it from the power source.
  - b. Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.
  - c. Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning or has been dropped or damaged in any manner
  - d. Use only in ponds and small decorative fountains.
  - e. DO NOT use in water intended for swimming, wading, immersion, or bathing.
  - f. Maximum depth: 18 in
  - g. Not for use with dimmers.
3. "WARNING - Risk of Electric Shock. Install power unit 5 feet (1.5m) or more from a pool or spa and 10 feet (3.05 m) or more from a fountain. Where the power unit is installed within 10 feet (3.05m) of a pool or spa connect power unit to a GFCI protected branch circuit."
4. Secondary cable is intended for shallow burial no more than 6 inches (153 mm) deep.
5. WARNING: Risk of Electric Shock. When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover
6. Close supervision is necessary when any appliance is used by or near children.
7. Always unplug an appliance from an outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank cord to pull plug from outlet. Grasp the plug and pull to disconnect.
8. Do not use an appliance for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition. Do not attempt to add additional secondary wiring or luminaries to Triple Light Set..
9. Do not install or store the appliance where it will be exposed to temperatures below freezing.
10. Read and observe all the important notices on the appliance.

## 11. SAVE THESE INSTRUCTIONS

### **FCC WARNINGS**

1. Changes or modifications not expressly approved by Spectrum Brands, Inc. could void the user's authority to operate the equipment.
2. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

3. **This device complies with Part 15 of FCC Rules.** Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

### **INSTALLATION & OPERATION INSTRUCTIONS**

1. Place lights in the desired location in the pond, outside the pond, or in fountain.
2. Mount Power Supply at least 1 foot (0.3 m) off the ground. Place the transformer in a place where it will not sit in a puddle when it rains. **DO NOT SUBMERGE THE TRANSFORMER IN WATER.**
3. . Do not use an extension cord
4. Transformer: Connect to a GFCI protected hooded flush type cover plate receptacle marked "wet locations while in use."
5. Secondary wiring (between transformer and lights) is intended for shallow burial of less than 6 inches (15 cm).

### **REMOTE CONTROL SETUP**

1. Ensure batteries are in place.
2. Hold down the remote control's ON button for 5 seconds.
3. Then plug the light into the power outlet while keeping the control's ON button compressed.
4. Wait until 5 seconds after the light is on to release the remote control's ON button.
5. Your remote control will now be functional.
6. Upon powering on, mode will be in default setting.

### **1 YEAR LIMITED WARRANTY**

1. United Pet Group, a division of Spectrum Brands, Inc. (UPG) warrants this product against defects in material or workmanship for one (1) year from the date of original purchase, subject to the conditions and exceptions stated below. Your sales receipt is your Proof-of-Date-of-Purchase. If the product exhibits such a defect, Spectrum Brands, Inc. will repair or replace it, at Spectrum Brands, Inc.'s option, without cost for parts or labor. The product must be shipped postage paid to UPG. Proof-of-Date-of-Purchase is required.

You are responsible for proper shipping. Call our Consumer Relations department at 1-800-526-0650 for return authorization and shipping address.

2. This warranty does not cover damage caused by accident, misuse, abuse or failure to follow the instructions accompanying this product. All implied warranties, including any implied warranty of merchantability or fitness for any purpose are limited to 1 year. Personal injury, property loss or damage (direct, incidental, or consequential) resulting from the use of this product are not covered by this warranty.
3. Because some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state/province to state/province.

#### **QUESTIONS? PROBLEMS? MISSING PARTS?**

Before returning the product, please call our Consumer Relations department at 800-526-0650, Monday–Friday 8:00 AM to 5:30 PM, Eastern USA Time or email us at [consumer@tetra-fish.com](mailto:consumer@tetra-fish.com). Please visit us at [www.tetrapond.com](http://www.tetrapond.com)!

#### **ADDRESS:**

United Pet Group, a Division of Spectrum Brands, Inc.

3001 Commerce Street, Blacksburg, VA 24060

1.800.526.0650 • [www.tetrapond.com](http://www.tetrapond.com)

® Registered Trademark of Spectrum Brands, Inc.

© 2016 Spectrum Brands, Inc. • Made in China