

Richmat 豪江


Richmat 豪江

Product function manual

Smart home

HJSR03 B1e

一、Remote control button silicone diagram



二、Remote control function description

Button label	Function
1	The motor runs to the ZG position with one key Memory function: Press FLAT first, then press ZG, the backlight flashes, the buzzer sounds, and the current motor position is recorded to ZG.
2	The motor runs to the SNORE position with one key Memory function: Press FLAT first, then press SNORE, the backlight flashes, the buzzer sounds, and the current motor position is recorded to SNORE.
3	The motor runs to the M position with one key Memory function: first press FLAT, then press the M key, the backlight flashes, the buzzer sounds, and the current motor position is recorded to M
4	One key reset, all motors retract to the minimum stroke position.
5	The head motor extends.
6	Foot motor retracts.
7	Head motor retracts.
8	The foot motor extends.
9	Press the flashlight to turn on, release the flashlight to turn off.
Coding method: [Remote head up + foot up (5, 6) + control box pairing key] The buzzer	

sounds, indicating that the pairing is successful.
--

Precautions:

To protect the reliability and safety of the motor and control box, do not switch the buttons frequently.

Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.