Blue LED Indicator
Indicateur DEL bleu
Indicador LED azul
(Pairing/Pairage/Emparejando)

Red LED Indicator
Indicateur DEL rouge
Indicador LED rojo
(Charging/Chargement/Cargando)

Key Functions

	Press	Press and Hold
⏻	**Play/Pause** or **Answer/End Call**	2 seconds**>Power On** 5 seconds**>Power Off**
⊖	**Previous Track**	**Volume Down** - Hold until desired level is reached
⊕	**Next Track**	**Volume Up** - Hold until desired level is reached
☼	**Light On** or **Light Off**	**Dim/Lighten** - Press button to change intensity of light

Connecting *Bluetooth®*

Step 1: Place the *Bluetooth®* Speaker and your device no more than one meter apart.

Step 2: Consult your device's manual to activate it's *Bluetooth®* function.

Step 3: To turn on the speaker, press and hold ⏻ button for about 2 seconds.

Step 4: Using your device, select "Verbatim BT LED" on the *Bluetooth®* Device List. The Blue LED Indicator will stop blinking and the speaker and your device will now be paired.

Power Off: Press and hold ⏻ button for 5 seconds.

Specifications

Specifications	
Speaker Output	5 Watts
Frequency Response	20Hz-20kHz
Operational Range	Up to 10 Meters
Continuous Speaker Output	Up to 15 Hours
Battery (Capacity)	Lithium Ion (4000mAh)
Charge Time	About 4 Hours
Light Output	1 Watt
Light Output Power	40 Lumens
Light Color	5500k-6500k
Continuous Light Output	Up to 20 Hours

Features and Benefits
- Adjustable LED light
- Convenient carrying handle
- IPX4 Rated (protected against splashing water for up to 5 minutes)
- Compatible with most *Bluetooth®* enabled devices
- USB Port to charge your devices
- Rechargeable Lithium Ion Battery
- Built-in microphone for hands free calling

This device has been tested in a controlled environment and certified to be water-resistant in specific situations (IPX4 classification described by the international standard IEC60529—Degrees of Protection Provided by enclosures). Despite this classification, this device is not impervious to water damage in any situation.

Maintaining Water Resistance
- Do not splash with water for more than 5 minutes. Ensure the back cover for the USB and audio jack is tightly closed when not in use.
- Do not open the back cover for the USB and audio jack with wet hands or when the device is wet.

Verbatim™

Bluetooth®

BLUETOOTH SPEAKER

Model: E-22

Users Manual