

KOVE




COMMUTER:2

BLUETOOTH STEREO SPEAKER SYSTEM

01

STEP ONE

Long press Master and Sub-Master "○" simultaneously for 2 seconds, you will hear a prompt tone of power on. Then the speakers will be connected automatically with a beep sound and the indicator light of sub-master will keep blue, master indicator light will keep flashing.




DEVICE:

COMMUTER:2

02

STEP TWO

Find "KOVE COMMUTER 2.0" in your bluetooth list and select it.




DEVICE:

COMMUTER:2

03

STEP THREE

The LED indicators on both speakers will keep blue once bluetooth is paired and a beep sound will be heard. You can play music now.




DEVICE:

COMMUTER:2

04

STEP FOUR

Long press Master and Sub-Master "○" simultaneously for 2 seconds to power on. Then the speakers will be connected automatically with a beep sound and the indicator light of sub-master will keep blue, master indicator light will keep flashing. (Please turn off bluetooth on your device before TWS paired)



DEVICE:

COMMUTER:2


K

FCC ID: 2AKAX-KOVE-179S

 RoHS CE FC  
MADE IN CHINA

- (1) Power Button/Multi-function Button
- Long press (1) for 2 seconds to Power On/ OFF
- Short press (1) to play/pause during music playing
- Short press (1) on master speaker to answer/end an incoming call
- Short press (1) twice on master speaker to reject a call
- Short press (1) twice to disconnect bluetooth
- Short press (1) three times to disconnect TWS
- (2) & (3) Power Button/Multi-function Button
- Short Press (2) to turn the volume up/Long Press (2) to next track
- Short press (3) to turn the volume down/Long press (3) to previous track
- Short press (2) & (3) simultaneously to turn on/off flashing white LED during music playing

Note: Both speakers can be controlled mutually after paired. If you are not able to connect two speakers successfully, long press (2) & (3) simultaneously of each speaker for 3 seconds to connect quickly.



INTERFACE INSTRUCTIONS

LED	Description
BLUE FLASHING	Bluetooth Pairing, Out of bluetooth Range
BLUE ON	Bluetooth Connected Successfully
RED ON	Charging
RED FLASHING	Low Battery
WHITE FLASHING	Music Playing
LED OFF	Fully Charged, Power Off



INTERFACE INSTRUCTIONS

PRODUCT NAME	Bluetooth Stereo Speaker System
MODEL NAME	"KOVE COMMUTER 2.0"
BLUETOOTH VERSION	5.0
BATTERY CAPACITY	1500mAh x 2
PLAY TIME	5-7 Hours (70% Volume)
CHARGING TIME	2-4 Hours
DRIVER UNITS	10W x 2
CHARGING CURRENT	5V 0.8A
PRODUCT SIZE	206.5*78.5*78mm
PRODUCT WEIGHT	860g

FAQ

Q: What kind of charger should we use for the speaker?
A: All common USB chargers can be used, while we suggest the ones above 5V/0.8A.

Q: What if there is noise or discontinuous sound when playing?
A: The speaker can be normally used within 10m under no obstruction environment. If it is over 10m or with obstruction, there might be noise or discontinuous sound.

Q: Why will the speaker shut down automatically when it is working?
A: When there is no bluetooth pairing 10 minutes, the speaker will shut down automatically to reduce power consumption.

Q: The speaker cannot connect to a previously paired cellphone.
A: First, remove the speaker's pairing name from the cellphone's bluetooth list and then short press the power button twice quickly to restart pairing mode.

Q: The speaker cannot be started up in a normal situation.
A: Please plug in the charger and try in a few minutes.

*This speaker supports mobile phones and tablet PCs etc. Here this User Manual is illustrated based on mobile phones.

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Dastmalchi LLC** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a Minimum distance of 5mm between the radiator and any part of your body.