


USER GUIDE


Parts



Specification

Model: M1
Earbuds dimension: 41.65mm*17.20mm*17.98mm
Bluetooth Version: 5.0
Interface type: type-C
Charging time : 1.5 hours
Battery Capacity: 30 mAh/400 mAh
Waterproof level: XPA
Microphone: double
N.W.: 48g(earbuds 3.8g *2, charging case 40.4g)

Parts



Charge the Battery

Charge the battery for ten minutes at least for the first charging or when the battery runs out
1. Put the earbuds into the case
2. Close the case and connect the cable

Caution:

- Please close the charging case when store or charge the earbuds or charge the charging case.
- It effects to charge if you touch the charging interface when it is charging into the charging case.
- It may corrode the earbuds if there is sweat or liquid on the charging connector.
If there is sweat or liquid on the charging connector and the earbuds, please clean them and put them into the charging case.
- Please do not use the earbuds at an incorrect position. If you put the earbus into an incorrect position, they can not be used.
- No adaptor is including for this product. Please pay attention to use the standard Type-C adaptor with certificated.

Before using

Please charge the earbuds and the charging case enough.

Starting up

Two earbuds start automatically when they are took out of the charging case.

Pairing & connection

- Take two earbuds out of the charging case and press any one of them to pair bluetooth if there is no pairing connection before. It is connected with the mobile device if there is a connection record.
- When the earbuds are in bluetooth pairing status, it stops to pair bluetooth if the earbuds can not be connected with the mobile device in 90 seconds, then press any one of the earbuds for 2 seconds, they enter into bluetooth pair status again.
- To connect with the other device but with a bluetooth pair record, it needs to delete the bluetooth pairing in the original device when there is a connection between the earbuds and the original device, then pair to the new device again.
- It shows the name of earbuds in the bluetooth list after pairing, which shows connection complete.

Turn off

Put the two earbuds into the charging case and disconnect with the phone, the earbuds turn off automatically after charging.

Operation

Click the induction zone on the earbuds, it plays / pauses music or accepts / rejects calls immediately

Pairing with mobile phones	Cover opening and pairing
	Automatically reconnected
Play/Pause	Double click the right earbud
	Double click the left earbuds if only use the left earbud
Volume+	N/A
Volume-	N/A
Previous song	Long press the left earbud
Next song	Long press the right earbud
Play/Pause	Pause playing when take out of ears
	Continue to play when put into ears again
Accept calls	Double click left/right earbud
Hang up calls	Double click left/right earbud
Reject calls	Long press any one of the earbuds for 2 seconds
Wake up voice assistance	Click the earbud for 3 times

Note

- The company reserves the right to modify the function, interface and appearance of the product without informing the user.
- Due to product version upgrade and other factors, if the description is different from the actual product, the actual product shall prevail.
- This product does not provide tools to upgrade firmware. If you try to use the third-party firmware by yourself, it may cause the product to fail and damage or lose data. These operations violate the "Three Guarantees service agreement" and will void your warranty.
- Do not let your device and battery suffer physical collision or damage.
- Do not let the charger socket and charging connector contact with metal, liquid or dust and other foreign matters.
- If any part of the equipment is damaged, smokes, or gives off the smell of burning, please stop using the equipment immediately. The equipment can only be used after repair.
- Do not open or use the device when the circuit board of the charging protection box is exposed.
- Do not remove or reuse the battery.
- Do not allow children or animals to chew or swallow the device.
- The equipment can be used in places with environment temperature between 0 °C and 35 °C. In the environment of low temperature, the equipment may be unable to charge, charge under charge, charging time increase and so on. It is recommended that you charge in a suitable temperature environment. You can store the device in an environment between -20 °C and 50 °C. Using or storing the device outside the recommended temperature range may cause damage to the device or shorten battery life.
- Do not use this equipment in high temperature environment or near fire.
- Please observe all safety warnings and regulations regarding the use of equipment while driving

Product quality warranty card

Customer's name: _____ Contact's number: _____

Contact's address: _____

Problem Description: _____

Add: No.3 Factory Building, Rongxing street, No.5 Industrial Zone, Xiegang Town, Dongguan City, Guangdong Province, China

Tel: +86-755-8696 9761

Warranty description:

Thank you for purchasing this product. In order to ensure your legal rights, please read the following carefully. This card is the product warranty certificate. When the product needs to be maintained, please provide this card with the product to the company for after sales service.

This card is only valid for use in products covered by the warranty, as detailed below.

- ① The company's products obtained through legal and formal channels;
- ② Non-human-damaged products, including but not limited to private disassembly, improper use, and natural disaster; lights are not covered by the warranty;
- ③ Not exceed the product warranty period;

*The precautions include and are not limited to the above.

*The company reserves the final explanation.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.