

Bluetooth Card reader

Product Manual

intelligent reader i21B



A. Download client side APP


(Support mobile OS: Android/iOS)

Download routes:


- Visit : www.itron.com.cn to download
- Scan QR code below to download

(Scan please)

B. Terminal Picture




The slot for Magnetic card swiping
The slot of Smart card



The 5V USB interface for charging
4 indicators are light on:power full
1 indicators are light on:power low



Power on/off



1.Push 2 secs to power on
2.Blue light binking means bluetooth connecting

Bluetooth connecting rule:


1. Turn on the card reader.
2. Turn on the cell phone bluetooth fuction.
3. Select the card reader by last 8 digits of the product.
4. Entry the last 4 digits of the serial number.

C. The product including & the lighting status

● The product inclucds:

1. The card reader
2. The USB connecting cable
3. The user manual

● Lighting status indiating:



D. Notes

1. Please make sure the bluetooth is connecting when the blue light is blinking before the swiping.
2. The red light should be off after successful swiping, if not, please swipe again !
3. If the swiping is fail, please check out the card is available or not, and your swiping way is stable or not? then check out the slot is clean or not ?
4. If the transaction is fail, Please check the network is network is available or not ?
5. Please do not disassembly the card reader, it will cause it malfunction.
6. The battery is inside, please prevent liquid introgresion and the fire.

E. Malfunction removal

Symptoms	Trouble shooting
Can not detect the card reader	Please confirm the card reader is turn on and bluetooth is connected
Swiping fail	<ol style="list-style-type: none">1. Please confirm the card reader and the cell phone is exactly connected2. Check out the operation status is swiping or not ?3. Check out the swiping slot is clean or not ?4. Check out the magentic card is damange or degaussed ?5. Try to use samrt card for transaction.

F. Malfunction removal

Symptoms	Trouble shooting
Can not read the card from swiping	<ol style="list-style-type: none">1. Swipe smoothly along the slot.2. The magnetic bar should downuend and face to you then swipe3. Try to swipe reversly too.

FCC ID:2AKC4-IT21B

Made in China

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.