

## **Caution:**

This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

Les antennes installées doivent être situées de façon à ce que la population ne puisse être exposée à une distance de moins de 20 cm. Installer les antennes de façon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne. La FCC des États-Unis stipule que cet appareil doit être en tout temps éloigné d'au moins 20 cm des personnes pendant son fonctionnement.

# Login

There are two methods to login for new users: Account login and Skip login

## 1.1 Account login

Open the App and make sure the Bluetooth is open. When register account, users need to click on “Register account” and input Mailbox, account name and password. After registering successfully, users need to enter the Mailbox to click the activation link for use “Account login” (Note: IOS system can slide to the right to return to homepage from registration page)Once register account created, users can enter into the homepage after login successfully.

## 1.2 Skip login

Click “Skip login” to login directly, and then enter into the homepage after login successfully. (Figure 1.1). Through “Skip login”, the data can only be saved in the phone, while through “Account login”, all operation data can be saved in account and controlled by different phone.

Figure 1









Figure 1.1






# Devices

1. Devices: Click “Devices” → “Add device” → “next” → to add devices. Or Click “Devices” → “+” → “Add device” → “next” → to add devices (Figure 1-4)





2. Once devices connected successfully, can find the devices in the device list. User can control on/off by pressing the icon on the right of the device list.

Users can edit the device as user preferred by clicking the icon on the left of the device list, such as rename, setting for brightness, CCT and colors.






# Rooms

- 1、Click “Rooms” to enter the page
- 2、click “+”
- 3、Input Room name and insert Room picture
- 4、Choose the device to be added in this Room, and then click “done”.




# Scenes

- 1、Click the “Scenes” and enter the page, then default scenes “Away from home” , “Back home” and “Rest” can be edited. Click the blank area at the right of the scene can perform it.
- 2、Click“scenes”on homepage, and click “+” in the middle to add new scenes or click “+” at the top-right corner and then click “Add scenes” on pop-up page to enter. Input scene name in this page and choose the devices, then click “next” to edit the action of the devices. After this, return to the previous step and click “ done”.



# Home

Home page: show scenes, all group, rooms and connected devices.



# Schedule task


1. Click “Schedule task” on setting page, and then click “Create a task” to enter next page, which can creat devices, rooms and scene tasks. Take create a scheduled task as an example in the figure below.



# General Settings

Click gear button to enter into setup page.

1. Reset password: Click to reset the account password.
2. Scheduled task: Create a scheduled task and support on multi-devices operation.
3. Firmware upgrade: Update the devices to the latest version.
4. Version information: Find the current APP software Version.
5. Operation instructions: Know more about APP operation.
6. Reset account: Reset the account to delete all connected devices.
7. About us: Know more about DongXing.



# Reset


1、Manual reset: make sure that the device is on for more than 5 seconds. Turn off the device, and repeat on and off for three times (every time stay off for 1-2 seconds), the restoration of the device happen in the forth time.

**For RGBW type, the device will flash red, green, blue, white, red, green and white alternately in turn until keep on after reset.**

**For Tunable White type, the device will flash white-yellow, white-yellow alternately until keep on after reset.**


**For ON/OFF/DIM type, the device will flash on and off twice until keep on after reset.**

2、App reset: click the “reset account” on setting page to reset the account. Reset will cause all added devices and data fall to zero.



# Firmware upgrade

1、Click “firmware upgrade” on setting page. If the device firmware is the latest version as shown in the figure, users do not need to upgrade it.



2、Click “firmware upgrade” on setting page. When the device can upgrade, click the red “upgrade” button and upgrade the device follow the instruction.

