


# USER MANUAL

## Bluetooth Earbud Defunc TRUE GO MINI



When charging, the first lamp from left to right is charged to 25%, the second lamp is flashed to 50%, the third is flashed to 75%, and the fourth is flashed to 100%. The power indicator is off.  
(Charging box can charge two headphones four times)

Thank you for choosing Defunc TRUE GO MINI !  
Please read this manual to optimize your experience.

### Pairing

Charge earbuds fully before pairing for the first time

1. Open the charging case, remove earbuds and earbuds will automatically power on and pair with each other
2. When the red lights on the right earbud (master earbud) flash alternatively, the earbuds are ready to pair with your device
3. Turn on Bluetooth on your device and select " Defunc TRUE GO MINI" in the Bluetooth list and accept pairing

### Hall switch

When open the charging case, earbuds will automatically power on and pair with each other

### Functions

**Power on:** Open the charging box cover, the headsets automatically turn on, automatic pairing

**Power off:** Put earbuds back in charging case and close cap. Auto-power off: Earbuds turn off after 5 min of not being paired

**Answer/end call:** Click the touch area of any earphone once to answer the incoming call and then once click to end it.

**Play/pause:** While listening to music, click the touch area of any earphone once for play&pause the song.

**Next track:** While listening to music, double click any earphone to next song.

**Previous track:** While listening to music, triple click any earphone back to previous song

**Voice assistant:** long press the touch area of any earphone 2S to activate the voice assistant (like siri function) and then long press 2 seconds to end it.

### Charging

Charge earbuds

Insert earbuds in charging case

Charging: the indicators on the earphones will be solid red

Fully charged: the indicator will be off

Charge case

Plug micro usb charging cable port into the device, plug other cable end into power source

Charging: Green lights flashing

Charging status: Each light equals 25% charged, all four indicators will be off once fully charged.

Case and earbuds can be charged simultaneously.

### Specifics

Bluetooth version: 5.0  
Transmission frequency: 2.4GHz  
Earbud battery: 30 mAh  
Charging case: 300 mAh  
Recharging: 4-5 times  
Talk time: ≈2.5 hrs (50%)  
Standby time: ≈130 hrs  
Charging time: ≈1.5 hrs  
Speaker:  $\varnothing 13\text{ mm} \times 24\Omega$   
Input interface: micro usb  
Net weight: ≈approx 42g  
Codex format: SBC

**Model: Defunc TRUE GO MINI**

**FCC ID: 2AKFED029**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### Included

True wireless earbud x2

Charging case x1

User manual x1

Warranty card x1

Thank you card x1

Manufacturer: Topalong Lean Supply (H.K) Ltd

Address of Manufacturer: Sanjiang Industrial Park, Hengli Town, Dongguan City,  
Guangdong Province, PRC.

### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.