

MESMART

Smart Door&Window Sensor User Manual



Download The APP

Note: Please read the user manual carefully before using our products and keep it safely




Brief Introduction

Work with smart home hub, real time detect open/close status of the door / window, remind the user on the APP if unexpected things happen.

Packaging content



Product Diagram




Product function



Installation Instruction

Step 1 Install battery



Step 2 Click "+" in APP when the hub is connected, and add the device



Step 3 Put on your door



Product Specification

Item	Smart Door & Window Sensor
Color	White
Power Supply	AAA battery *2
Wireless standard	ZigBee IEEE 802.15.4
Operating Temperature	-10°C~50°C
Operating Humidity	0%~95% RH

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.