



## Remote Control Instruction



### BATTERY REPLACEMENT



3 Volt, CR2025 battery included

### RESETTING REMOTE CONTROL

• Adding or replacing remote control

• Remote is not working correctly

**1. Turn power OFF**

**2. Press and hold ON button**

**3 Turn power ON**

Bulb will flash 3 times

You've successfully programmed your remote.

### REMOTE CONTROL

(See illustration)

- 1** ON: Turns the lights ON.
- 2** OFF: Turns the lights OFF.
- 3** INCREASE/DECREASE BRIGHTNESS: Press ( $\Delta$ / $\nabla$ ) to choose brightness level. (Only works in single color mode)
- 4** COLOR CHANGING SPEED: Press (-/+) to decrease or increase the color changing speed. (only works in color combination mode)
- 5** MODE BUTTON: Press button to select one of the 9 color combination modes. (see chart to right)
- 6** RED: Press to change string light color to RED.
- 7** GREEN: Press to change string light color to GREEN.
- 8** BLUE: Press to change string light color to BLUE.
- 9** WHITE: Press to change string light color to WHITE.



### MODE BUTTON FUNCTIONS

1. Red to green
2. Red to blue
3. Red to white
4. Green to blue
5. Green to white
6. Blue to white
7. Red to green to blue
8. Red to white to blue
9. Red to green to blue to white

## **Federal Communications Commission (FCC) Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

## **Industry Canada (IC)**

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la norme RSS d'Industrie Canada. Son fonctionnement est sujet aux deux conditions suivantes:

(1) led dispositif ne doit pas produire de brouillage préjudiciable, et

(2) ced dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.