


文件名称: Bot英文版说明书	设计师: HJ	完成时间: 2021/03/11
版本号: Bot-EN-2103	成品尺寸: 70*75mm	
材质和工艺: 风琴折 内页128G铜版纸 顺序打样, 红色指定为PMS-2034C		
更改内容: 修改文案, 新增清理沾面的说明		


SwitchBot Bot

User Manual


Model: SwitchBot-S1




In The Box




Bot (CR2 battery included)



User manual




2 add-ons





1 spare sticker



Getting Started

1 Remove the plastic battery isolation tab.




2 Download the SwitchBot app.







3 Enable Bluetooth on your smartphone.



4 Open the SwitchBot app and tap the Bot icon on the Home page to control it. If the Bot icon does not appear, swipe down to refresh the page.




5 Install Bot near the switch using the sticker. Note: Make sure the surface is clean and dry before applying the sticker. Then wait for at least 24 hours for the adhesiveness to take effect.



Add to SwitchBot Account


Create a SwitchBot account and sign in from the app's Profile page. Then add Bot to your account. Learn more at, support.switch-bot.com/hc/en-us/articles/360037695814




Mode

The execution mode of Bot can be changed on the Settings page in the app.

Press mode: for push button or one-way control switches



Switch mode: for push and pull switch (for use with add-ons)



Voice Control


Alexa, turn on the living room light*.

Hey Siri, make me a coffee**.

OK Google, turn off the bedroom light*.


* Bot's alias set in the SwitchBot app.
** Personalized phrase recorded in Siri Shortcuts.


If you have a SwitchBot Hub Mini (sold separately), you can control Bot remotely using voice control services*.
* Enable Cloud Service first before using voice control services.
Learn more at, support.switch-bot.com/hc/en-us/sections/36005960714



www.switch-bot.com

Setup and Troubleshooting: support.switch-bot.com
Support Email: support@wondertechlabs.com






Replace the Battery

1 Prepare a CR2 battery.


2 Remove the cover from the notch on the side of the device.

3 Replace the battery.

4 Install the cover back on the device.




Learn more at, support.switch-bot.com/hc/en-us/articles/360037747374



Reset the Device

Remove the cover and press the reset button, the device's password, mode and timer will be restored to the factory state.



Disclaimer of Warranties

- Only for use in dry rooms. Do not use your Device near sinks or other wet locations.
- Do not expose your SwitchBot to steam, extreme heat or cold. For example, do not plug in your SwitchBot near any heat sources such as space heaters, heater vents, radiators, stoves, or other things that produce heat.
- Your SwitchBot is not intended for use with medical or life support equipment.
- Do not use your SwitchBot to operate equipment where inaccurate timing or accidental on/off commands could be dangerous (e.g. saunas, sunlamps, etc.).
- Do not use your SwitchBot to operate equipment where the continuous or unsupervised operation could be dangerous (e.g. stoves, heaters, etc.).

Return and Refund Policy

SwitchBot Bot has one year warranty (start from the purchasing day). The situation below do not fit the Return and Refund Policy

- Intended damage or abuse.
- Inappropriate storage (drop down or soaking in water).
- User modify or repair.
- Using loss.
- Force majeure damage (Natural disasters).

If you have any concern or problem when using our products, please kindly send feedback from the Profile > Feedback page in the SwitchBot app.

CE Warning

1.Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

2.The operating temperature of the EUT can't exceed 55°C and shouldn't be lower than 0°C. Hereby, Woan Technology (Shenzhen) Co., Ltd. declares that the radio equipment type SwitchBot-S1 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.switch-bot.com.

This product is allowed to be used in all EU member states.

3. RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20mW specified in EN62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation(1999/519/EC).

FCC Warning

FCC regulatory conformance
FCC ID: 2AKXBBOT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reason-able protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance

with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encourage to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

KC Warning

인증받은자의 상호: Woan Technology (Shenzhen) Co., Ltd.
제품명/모델명: 특정소출력 무선기기(무선데이터통신시스템용 무선기기) / SwitchBot S1
제조사 및 제조국가: Woan Technology (Shenzhen) Co., Ltd./China
제조년월: 2019.10
인증번호: R-C-24K-SwitchbotS1
이 장치는 보안성이 없으므로 통신보안에 위배되는 사항의 통신을 금지하여 운용 중

NCC 警語：

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。