User Manual

Elwing Remote Control

Model No.: E1-001



figure 1





figure 3



figure 4

Above for the local figure of the remote control

As shown in figure 1: this chart shows the acceleration and braking function of remote control, orange for the brake and accelerator control switch, SPEED UP to accelerate forward, BREAK for the brake.

As shown in figure 2: the diagram shows the FORWARD function, FORWARD FORWARD to move FORWARD.

As shown in figure 3: the diagram shows for the remote control switch function, ON to open, OFF to OFF.

As shown in figure 4: the diagram shows the fast and slow function, when switch to one side of the engraved with the tortoise design for slow mode, when the switch to one side of the engraved with the rabbit design for fast mode.

Note: first need when using the remote control and skateboard matching connection (factory default has matching), turn on switch skateboard when they pair up and then press the pairing button on the skateboard, skateboard pairing LED normally on at this time, to make the remote control switch in the BACKWARD, BREAK the turtle slow mode, then turn on the switch, when you see the LED lights on the remote control fast blink a few times, skateboard pairing leds start flashing to match has been successful.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.