

Wireless Remote Control LTR05

This Product is a Wireless Remote Control, which has two buttons.

OPERATION:

1. Press "ON" button on the Remote to power ON outlets
2. Press "OFF" button on the Remote to power OFF outlets.



BATTERY INFORMATION AND REPLACEMENT:

One CR2032 3-Volt battery included in transmitter.

1. To replace, slide off the battery cover from the back of Remote Control.

Make note of the location of the positive side of the battery.

2. Remove the used battery and insert a new CR2032 3-Volt battery.

Confirm that the polarity is correct. When facing the battery compartment from the back of the remote control, the positive side faces up.

3. Slide the cover back.

4. Dispose of old battery properly.

WARNING:

The remote control is not a toy. Keep batteries and remote control away from children and pets. Follow the battery manufacture safety and usage instructions. Remove battery if product is to be left unused for a long time.

Clean the battery contacts and also those of the device prior to battery installation. Do not use as permanent source of power.

Do not exceed electrical ratings.

CAUTION: Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: *This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.*

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.