














客户品牌：GEHA	备注： 第一版，
产品型号：GHZK200B	
设计项目：说明书	
文件名称：K200_GEHA_GH-K200_说明书_折页_01	
说明书尺寸：60mm X 90mm（展开尺寸：300mm X 90mm）	
工艺说明：105g铜板纸，单色正反面印刷，折页（折扇形）。	
制作版本：01	

300.0 mm				
60.0 mm				
90.0 mm				
	<div><div></div><div></div><div>GHZK200B Instruction manual</div><div>AMPLIFY YOUR EXPERIENCE</div></div>	<div><div>SPECIFICATION</div><div><ul style="list-style-type: none">· Model: GHZK200B· BT: V5.3· Waterproof: IPX4· Battery: 7.2 / 2550mAh· Charging time: 3-4 hour· Playtime: 6-8 hour (50% Volume)· USB output: 5V / 2A (MAX)· Output: 30W· Size: 76 * 83 * 201 mm· Weight: 550 g</div></div> <div><div>WHAT IS IN THE BOX</div><div><div><div>x1 Speaker</div></div><div><div>x1 Type-C USB cable</div></div><div><div>x1 User Manual</div></div></div></div>	<div>Buttons and functions</div> <div><div>1.  RGB Light button</div><div>Short press to switch one light effects and light off.</div><div>2.  V+ /Next</div><div>Short press: increase volume, the bottom light bar shows volume level.</div><div>Long press: next song, press and hold in AUX mode to increase the volume.</div><div>3.  MODE button</div><div>Short press MODE to switch BT.</div><div>Long press and hold for 2 seconds to disconnect phone or reconnect to the last disconnected phone.</div><div>4.  Power button</div><div>1). Long press and hold for 2 seconds to turn it on / off.</div><div>2). When the machine crashes, press and hold for 10 seconds to shut down and reset.</div><div>5.  Broadcast button</div><div>Short press: turn on / off broadcasting connect.</div><div>6.  V- /Prev</div><div>Short press: decrease volume, the bottom light bar shows volume level.</div><div>Long press: for the previous song, long press in AUX mode will reduce the volume.</div></div>	<div><div>7.  Play and Pause</div><div>short press music play and pause functions.</div><div>Long press and hold for 5 seconds to clear pairing information and restore the default volume with a prompt sound.</div><div>It will automatically shut down.</div><div>8. Charging indicator.</div><div>9. TYPE-C charging port</div></div> <div><div></div></div>

正面

正面

<p>Broadcast</p> <p>Support to link wirelessly more than 100pcs GH-K200 compatible speakers together, and the host speaker (GH-K200) can control all other broadcast speakers (including power off).</p> <p>1) Turn on the speaker, and Bluetooth connect with GH-K200 party speaker (The host speaker); short press the power button to turn on the broadcast, the broadcast indicator is on.</p>	<p>3) When the host speaker short press the power button to turn off the broadcast, all the secondary machine broadcast will be turned off. When the secondary machine short press the power button to turn off the broadcast, only this speaker broadcast will be turned off, other speakers are not affected.</p> <p>FAULT AND MAINTENANCE</p> <p>First fault: connection failed.</p> <p>Solution:</p> <p>(1) Please check whether the multifunction indicator light flashes white. Please power on your speakers if the light isn't on. Please charge the speaker if the light is still not on.</p> <p>(2) Please turn off the other Bluetooth devices, if there are many Bluetooth devices surrounding. This may result in search difficulties.</p> <p>(3) Restart wireless speaker on devices for Bluetooth search function.</p> <p>Second problem: The music player appears sound breaks.</p> <p>Solution:</p> <p>(1) View the distance between the player and the speaker has not been exceeded effective Bluetooth connection distance 8-12meters.</p>	<p>(2) Ensure there is not any obstacle between the play device and speakers.</p> <p>(3) Check the playback device or whether the speaker is in a low power state.</p> <p>NOTES BEFORE USE</p> <p>This product is designed with full attention for safety performance. To ensure safe operation, please follow the following rules:</p> <ol style="list-style-type: none">Place the speakers in a stable position avoid fall and cause damage or personal injury.Do not drop, disassemble, open, crush, bend, puncture, burn speaker.Do not close to any heat source (such as radiators, heating equipment, stoves, or other heat-generating equipment) where the use of speakers.Please send professional maintenance staff to repair for any reason damage.Before wiping with a dry cloth to clean the speakers, set the power switch to the off position and unplug the power cord from the power outlet.Health considerations, please adjust the sound to a suitable level. <p>WARNING:</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>	<p>FCC Warning</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.- Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p>TROUBLESHOOTING</p> <p>The speaker does not turn on ?</p> <p>Recharge your speaker.</p> <p>The speaker does not turn off or does not respond ?</p> <p>Reset your speaker, hold the power button for 10 seconds to automatically reset the speaker and turn it off .</p> <p>There is no sound?</p> <p>Adjust the volume. Make sure that your Bluetooth device is within range. Ensure there is no obstacles in the way that can block/disturb the signal. Check via the device's Bluetooth connection if the speaker is connected with the device.</p> <p>There is poor sound quality?</p> <p>Move the device closer to the speaker or try removing obstacles between them.</p> <p>Cannot connect the device with the speaker?</p> <p>Disconnect other connected devices and then try again. You can force a disconnection by moving out of Bluetooth range (10 m).</p> <p>In order to avoid harming the product performance, please do charge your device each 3 months at least.</p>
---	---	---	--	---

反面

IC Warning

This device complies with Innovation, Science and Economic Development Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux normes RSS d'Innovation, Sciences et Développement économique Canada en matière d'exemption de licence. Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences; et
- (2) Cet appareil doit accepter toute interférence, y compris celles qui peuvent entraîner un fonctionnement indésirable de l'appareil.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF.
L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables.