

**JVC****SP-WS2BT**PORTABLE WIRELESS SPEAKER  
ENCEINTE SANS FIL PORTABLE

CONFIDENTIAL

**STARTUP GUIDE  
GUIDE DE DÉMARRAGE**

**For Customer Use:**  
Enter the Model No. and Serial No. below.  
Retain this information for future reference.  
**Model No.**  
**Serial No.**

**Manufacturer**  
JVC KENWOOD Corporation  
3-12,Moriya-cho,Kanagawa-ku,Yokohama-shi, Kanagawa, 221-0022, JAPAN

<https://manual3.jvckenwood.com/accessory/headphones/global/>

**For detailed operations, troubleshooting and information on the European Guarantee, please refer to the user manual.**  
Pour les opérations détaillées, le dépannage et les informations sur la Garantie européenne, veuillez vous reporter au manuel de l'utilisateur.

© 2025 JVCKENWOOD Corporation

01-85A-4832-00

**For U.S.A. and Canada**

IC:XXXXXX-XXXXXX

FCC ID:XXXXXX-XXXXXX

**ATTENTION:**  
The product you have purchased is powered by a rechargeable battery that is recyclable.  
Please call 1-800-4-BATTERY for information on how to recycle this battery.

English

**For U.S.A.**

Supplier's Declaration of Conformity

Model Number: SP-WS2BT

Trade Name: JVC

Importer: JVCKENWOOD USA Corporation

Address: 1440 Corporate Drive, Irving, TX 75038

Telephone Number: 678-446-8079

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

**For Canada**  
CAN ICES-3(B)  
This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:  
1. This device may not cause interference.  
2. This device must accept any interference, including interference that may cause undesired operation of the device.


**For Canada**

NMB-3(B)

L'ultimo/ultimo émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'émission est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage.

2. L'appareil doit accepter tout brouillage radioélectrique subi, même si ce brouillage est susceptible d'en compromettre le fonctionnement.

**How To Use****Charging  
Chargement**


- The L indicators flash and light up in white indicating that charging has started.
- When charging is complete, all the L indicators light up in white.
- The L indicators flash and light up in white indicating that charging has started.
- When charging is complete, all the L indicators light up in white.

- Charging time: approx. 4.0 hours (when the power is off)
- Charging time: approx. 4.0 hours (when the power is on)




**Connecting Connexion**

**1 Turn on the speaker.**  
Turn on the speaker.




When the L indicators don't flash quickly, press and hold the pairing button for about 1 second.  
When the L indicators don't flash quickly, press and hold the pairing button for about 1 second.


**2 Connect the speaker to the BLUETOOTH device.**  
Connect the speaker to the BLUETOOTH device.




The L indicators light up in blue.  
The R indicators light up in blue.

**Operation Opération**


**▶/II** 

**◀** 

**▶+** 

**Connecting to the external device**  
**Connecting to the external device**

**1** Use an audio cable to connect the external device to the AUX IN terminal of the speaker.  
Use an audio cable to connect the external device to the AUX IN terminal of the speaker.



Bluetooth connection is disconnected, and input is automatically switched to AUX IN.  
Bluetooth connection is disconnected, and input is automatically switched to AUX IN.

**2** Playback music via external device.  
Playback music via external device.




**Stereo Pairing**  
**Stereo Pairing**

By placing two speakers on the left and right like stereo speakers, you can enjoy more immersive sound.  
By placing two speakers on the left and right like stereo speakers, you can enjoy more immersive sound.

**1** Prepare 2 speakers. First, connect the L speaker to the BLUETOOTH device.  
Prepare 2 speakers. First, connect the L speaker to the BLUETOOTH device.




**2** Turn on the R speaker, and make sure that all the L indicators flash twice slowly.  
Turn on the R speaker, and make sure that all the L indicators flash twice slowly.



**3** ① Press the MODE button of the L speaker for about 1 second.  
Press the MODE button of the L speaker for about 1 second.  
• The R indicator of the L speaker flashes alternately between blue and red.  
• The R indicator of the L speaker flashes alternately between blue and red.

② Press the MODE button of the R speaker for about 1 second.  
Press the MODE button of the R speaker for about 1 second.  
• The R indicator of the R speaker flashes alternately between blue and red.  
• The R indicator of the R speaker flashes alternately between blue and red.

**4** Stereo Pairing of the L and R speakers are completed.  
Stereo Pairing of the L and R speakers are completed.  
• The R indicator of the L speaker lights up in Blue, and the R indicator of the R speaker lights up in red.  
• The R indicator of the L speaker lights up in Blue, and the R indicator of the R speaker lights up in red.



You can now listen to music.  
You can now listen to music.