

Troubleshooting:

1. If the additional speakers do not connect to the 1st speaker or you do not hear an audible beep sound when pairing the additional speakers, please double press the ON/OFF button on the additional speakers again.
2. If your device is an Apple product, make sure only 1 “UUFFOO” record is in the device list, otherwise, you will not be able to pair. To fix this, simply have your device “Forget this Device” on any additional “UUFFOO” devices leaving only 1.

Theater Solutions by Goldwood™

Model:B41GG

Bluetooth Rock Speakers

Congratulations on your purchase and welcome to the world's finest brand of audio equipment. If you ever have questions on your product, please contact your authorized dealer and their highly experienced staff will be more than willing to help. Please read the following manual carefully before installing, connecting or adjusting your new speaker.

Made in China

www.goldwood.com

www.goldwood.com

Bluetooth Function:

1. Make sure battery is fully charged before attempting to connect the first time.
2. Starting with the 1st rock speaker, press and hold the ON/OFF button on the bottom of the rock speaker. There will be an audible activation beep and the indicator light will flash.
3. On your phone, turn Bluetooth to "ON" and select "**UFFOO**" in your Bluetooth device list. Once device is connected you will hear a second audible beep from the speaker and the indicator light will be blue.
4. **PAIRING:** To connect with additional speakers (**the 2nd, 3rd...99th speakers**), quickly double press the **ON/OFF** button on each additional speaker. You will hear a beep sound from the additional speaker. Once paired, you should hear the music playing in a while. To cancel, the pairing, quickly double press the **ON/OFF** button. No beep will be heard when turning the speakers off.
5. To turn off the Bluetooth function, press and hold the **ON/OFF** button.

Outdoor Installation:

When choosing a place for your speakers, try to choose an area on a higher surface to avoid the speaker sitting in water build up and to maximize drainage around the speaker. Place it on a flat surface, not tilted, so no water can build up underneath. In the winter months or during long periods without use, it is a good idea to bring indoors to maximize speaker life.

Note: Submerging speakers in water (pool or spa) will cease function and void your speaker's warranty.

Battery Operation:

1. Please charge the battery fully before first use.
2. Connect the USB adapter to the speaker using the charge port. While battery is charging the indicator will be red.
3. Charge the battery until the indicator light is off.
4. After the battery has been charged, turn on the speaker and the indicator should be blue. Then follow Bluetooth function instructions.

Note: The built-in battery is not replaceable. Please do not remove or replace it in the trash. If you must dispose of this speaker, bring it to your local recycling center.

Precautions:

- The USB Cable is not waterproof, please only charge the battery indoors.
- this product should never be submerged in water
- disconnect the power adaptor from the outlet when not in use
- do not stand or jump on this product
- keep this product away from chemicals and high heat
- do not attempt to disassemble the speaker
- do not use this product outdoors if they are cracked or damaged
- do not use these speakers as a floating device

Features:

- Weatherproof against rain, snow, ice, salt, pool chemicals, etc.
- Built In Bluetooth Receiver
- Rust Resistant Grills
- Silicone Sealed, Multilayer Composite Cabinets made with Hi-Tech Resin
- Butyl Rubber Surrounds
- Voiced for Outdoor Performance
- 2- Way Design and Functionality

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.