

Troubleshooting

No power from speaker	Recharge your microphone using the included adapter
Music is not playing over Bluetooth	Make sure your Bluetooth device has A2DP profile. Check if device is paired and connected over Bluetooth. Restart speaker.
Bluetooth device will not reconnect with the microphone	Navigate to the Bluetooth settings menu on your device. Tap "UB S062B" and select "Forget." Now follow the steps to pair your device again.

Specifications:
 Power output: 5W
 Frequency: 100Hz-10KHz (Horn frequency response range)
 Driver: 1.8 inch
 Built-in Battery: Lithium 1200mAh
 Playback time: Approx. 6 Hours*
 Charging time: Approx. 2 hours
 Standby time: Approx. 50 hours
*Approximate playback time. Battery life depends on individual use and may be slightly more or less than the time specified.

Technical Support:
 If you are experiencing problems, do not attempt to fix the product yourself or return it to the store you purchased it from. Please refer to the user's manual or just contact our helpful tech support team:
 Merkury Innovations
 45 Broadway, 3rd Fl
 New York, NY 10006
www.merkuryinnovations.com
 support@merkuryinnovations.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation.

©2020 Merkury Innovations, LLC.
 To explore our full selection of products, visit us at: www.merkuryinnovations.com
 The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google, Google Play, and related marks and logos are trademarks of Google LLC. All other trademarks and trade names are those of their respective owners. The illustrated product and specifications may differ slightly from those supplied.
 Made in China




PROSTAR

Pro Wireless Karaoke Speaker

Sing along with your favorite karaoke apps or YouTube karaoke videos



Download on the App Store



GET IT ON Google Play



YouTube

User's Manual for UZ-S062B

Included:
 Wireless Speaker
 USB Cable
 User Manual

IMPORTANT Please read before using this product

Charge It

- Plug the micro USB cable into the micro USB port on the side of the microphone. Connect the other end of the cable with any compatible charger, wall outlet or USB port.
- When charging, the LED indicator will glow red. Once fully charged, the LED indicator will turn off.
- Charging time is approximately 2 hours.

Turn It On/Off

- Press and hold the power button on the front of the microphone to turn it ON and OFF.
- The speaker will emit a tone, and the LED indicator will turn on.
- Press the power button again and the microphone will turn off.

Pair & Connect with a New Device

- Turn the microphone on. The blue LED will flash and it will automatically go into pairing mode.
- On your Bluetooth-enabled device, navigate to the Bluetooth settings menu, and search for new devices. Wait a few seconds and select "UB S062B."
- The speaker will emit a tone when successfully paired.

NOTE: If asked for a password, you may need to enter "0000."

Play

- Connect your device to the microphone via Bluetooth. (See "Pair & Connect with a New Device.")
- Open your favorite music or karaoke app and press play.
- Control the tracks & volume from the microphone or use your device.
- Press in the "▶" button once to play/pause music.
- Short Press "◀" or "▶" to raise or lower volume. Long press to the next/previous track.
- Slide "MIC VOL" to raise or lower the microphone volume.
- Slide "REMX" to raise or lower the reverb effect.

NOTE: Volume levels on your device and on the speaker are controlled separately.

Mic Volume and Echo


- Achieve a unique sound using the control sliders to effect the microphone's audio.
- Volume - Raise and lower the volume of the speaker.
- Mic Volume - Control the volume of your voice through the speaker.
- Reverb - Adjust the amount of reverb effect added to your voice.
- LED - Press the LED button to turn on/off LED lights.

Reconnect to Bluetooth

- You only need to pair your Bluetooth device with the microphone once.
- With your previously paired device's Bluetooth turned on and in range, power on the microphone.
- The microphone will automatically reconnect to the last Bluetooth device it was connected to.
- If a previously paired device does not auto-reconnect, navigate to the Bluetooth settings menu on your device, and select "UB S062B" from the list of Bluetooth devices.

Karaoke App Support

- The PROSTAR supports many apps found in Apple and Android App store.
- Try out some of these popular apps: Smule, The Voice: On Stage, Karaoke Sing and Record, Yokee: Sing Like A Star!, and StarMaker
- The microphone also supports using YouTube for your karaoke music and lyrical needs.
- Just search for karaoke songs and press play.



FRONT

- Micro USB Charging Input
- TF Card
- USB
- AUX Port

Located on the side

- Microphone Volume
- Reverb/Echo Volume
- On/Off LED Lights
- Next/Previous
- Audio Function

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **SHENZHEN HOTOP ELECTRONIC TECHNOLOGY CO.,LTD** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The device compliance RF exposure requirement and can be installed and used without restriction.