Please do as the below battery operating instruction before running the appliance:


1. Make sure the appliance is power off before installing the battery fuse.

2. Open the fuse cover with tilting down force.

3. Press the fuse into the fuse holder fully, close the cover well.

4. Power on, ready to start the unit.

⚠ 1.Avoid the battery fuse in connection mode if the device is not used for a long period of time.
2.According to the date of manufacture, please recharge the battery once every 3 months, recommend charging level ≥75%

Date of manufacture:

CONTACT:
Falcon Sound & Lighting
Web: www.AUDSTER.com
Email: Info@AUDSTER.com

AUDSTER

Professional Amplified Speaker System
With USB, MMC, FM, BT, REC
Instruction Manual

Thank you very much for buying this speaker box,please kindly read instruction manual before operating the product

Product:Professional Amplified Speaker System

Model:PR-12BAT

Technical Specification:

1.Amplified plastic loudspeaker.

2.Woofer:12", 50 Oz, 65mm VC.
   Tweeter: 34mm Ti driver

3.Frequency response:45Hz-20KHz

4.Sensitivity:98±2dB

5.With USB, MMC, FM, BT and REC

6.Power:4000W

7.Voltage:AC110V/220V

Notes:

Please read the entire attached document carefully

before using the device for your reference.

The power supply must match the demand of the device with reliable ground wire.

All covering signal should be complied with the demand of device.

The device should be equipped far away high temperature, moisture and powerful electro and magnetic

field.

Please don't use the organic cleaner but dry soft cloth to clear the device.

When not in use, unplug the unit from the mains.

Set the unit to the lowest volume prior to switching it on.

Only use suitable means of transportation if you want to move the speaker box-BE WARE OF YOUR

BACK!

Button	Function
MODE	Short Press: Switch between USB/MMC/FM/BT Long Press: ON/OFF MP3
▶II	Play/Pause FM Mode：Auto Search
REC	RECORD
↺ EQ	Short Press: Switch between RO/RA/RR Long Press: Switch between EQ mode（6 TYPES）
I◀◀	Short Press: Last / CH-(FM) Long Press: Quick return
▶▶I	Short Press: Next / CH+(FM) Long Press: Fast forward
VOL-	Volume down
VOL+	Volume up
F-	File down
F+	File up

Number of files

Number of songs

} AVAILABLE WHEN USING WITH NUMBER BUTTON TOGETHER

SPECIAL FOR MP3

1. MMC Port
2. USB Port
3. Control button of USB. MMC. FM. BT. RECORD
    REC: RECORD is to put a USB/MMC in the speaker, through MIC/Line in, it could to
          record the information within the USB/MMC
4. Bluetooth light:
    Red: Indicating searching for Bluetooth name, Blue: Indicating matched
5. Remote Window
6. LCD Display
7. MIC 1 input
    Microphone input with XLR connector and 6.35 connector line input.

8. Stereo Line Input
9. Stereo Line Output
10. Graphic Equalizer
    Use the function to adjust the high-middle-low effect
11. Time and Repeat Effect
12. Master Level
13. Effect Leve
14. MP3 and Line Level
    Adjust this knob, you can reach the effect you want.
15. MIC Priority selection:
    When it is on status: MIC Priority could work(When the volume of microphone reaches a certain
    loudness, the loudness of music will decrease); Whe it is off: MIC Priority couldn't work.
16. Antennas of Wireless microphone
17. ON/OFF button
    When it is on status, the wireless microphone could work; when it is off, the
    microphone couldn't work.
18. Volume control of wireless microphone
19. Voltage Switch
20. Power Socket
21. Power Switch
22. DC Input/DC Output
23. Battery FUSE
24. Battery indicator
25. Speaker Output

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following twoconditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one ormore of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **NingBo Lisound Audio Equipment Co., Ltd.** may void the FCC authorization to operate this device.Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.