



Professional Amplified Speaker System
With USB, MMC, FM, BT, REC
Instruction Manual

Thank you very much for buying this speaker box, please kindly read instruction manual before operating the product

Product: Professional Amplified Speaker System

Model: PR-15BAT

Technical Specification:

1. Amplified plastic loudspeaker.
2. Woofer: 15", 60 Oz, 75mm VC.
Tweeter: 44mm Ti driver
3. Frequency response: 45Hz-20KHz
4. Sensitivity: 98±2dB
5. With USB, MMC, FM, BT and REC
6. Power: 5000W
7. Voltage: AC110V/220V

Notes:

Please read the entire attached document carefully before using the device for your reference.

The power supply must match the demand of the device with reliable ground wire.

All covering signal should be complied with the demand of device.


The device should be equipped far away high temperature, moisture and powerful electro and magnetic field.

Please don't use the organic cleaner but dry soft cloth to clear the device.

When not in use, unplug the unit from the mains.

Set the unit to the lowest volume prior to switching it on.

Only use suitable means of transportation if you want to move the speaker box-BE WARE OF YOUR BACK!




CONTACT:

Falcon Sound & Lighting

Web: www.AUDSTER.com

Email: Info@AUDSTER.com



1. MMC Port
2. USB Port
3. MIC Level

4. Control button of USB. MMC. FM. BT. RECORD

REC: RECORD is to put a USB/MMC in the speaker, through MIC/Line in, it could to record the information within the USB/MMC

5. Bluetooth light:

Red: Indicating searching for Bluetooth name, Blue: Indicating matched

6. Remote Window

7. LCD Display

8. MIC 1 input

Microphone input with XLR connector and 6.35 connector line input.

9. MIC 2 input

Microphone input with XLR connector and 6.35 connector line input.

10. MIC EFF

11. Stereo Line Input


MODE	Short Press: Switch between USB/MMC/FM/BT Long Press: ON/OFF MP3
▶▶	Play/Pause FM Mode: Auto Search
REC	RECORD
EQ	Short Press: Switch between RO/RA/RR Long Press: Switch between EQ mode (6 TYPES)
◀◀	Short Press: Last / CH-(FM) Long Press: Quick return
▶▶	Short Press: Next / CH+(FM) Long Press: Fast forward
VOL-	Volume down
VOL+	Volume up
F-	File down
F+	File up



Number of files

Number of songs

} AVAILABLE WHEN USING WITH NUMBER BUTTON TOGETHER



12. Stereo Line Output

13. Button to switch between line and USB/MMC/FM/BT

14. Graphic Equalizer

Use the function to adjust the high-middle-low effect

15. Time and Repeat Effect

16. Master Level

17. MP3 and Line Level

Adjust this knob, you can reach the effect you want.

18. Volume control of wireless microphone

19. Antennas of Wireless microphone

20. ON/OFF button

When it is on status, the wireless microphone could work; when it is off, the microphone couldn't work.

21. MIC Priority selection:

When it is on status: MIC Priority could work(When the volume of microphone reaches a certain loudness, the loudness of music will decrease); Whe it is off: MIC Priority couldn't work.

22. Voltage Switch

23. Power Socket

24. Power Switch

25. Battery Fuse

26. Speaker Output

27. Battery indicator

28. DC Input/DC Output

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **NingBo Lisound Audio Equipment Co., Ltd.** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.