NVNT	ac20	5825	Ant2	-6.03	0	-6.03	30	Pass
NVNT	ac20	5825	Sum	-1.83	0	-1.83	27.9	Pass
NVNT	ac40	5190	Ant1	-2.81	0	-2.81	11	Pass
NVNT	ac40	5190	Ant2	-2.28	0	-2.28	11	Pass
NVNT	ac40	5190	Sum	0.47	0	0.47	8.9	Pass
NVNT	ac40	5230	Ant1	-3.08	0	-3.08	11	Pass
NVNT	ac40	5230	Ant2	-2.3	0	-2.3	11	Pass
NVNT	ac40	5230	Sum	0.34	0	0.34	8.9	Pass
NVNT	ac40	5270	Ant1	-6.12	0	-6.12	11	Pass
NVNT	ac40	5270	Ant2	-6.07	0	-6.07	11	Pass
NVNT	ac40	5270	Sum	-3.08	0	-3.08	8.9	Pass
NVNT	ac40	5310	Ant1	-6.31	0	-6.31	11	Pass
NVNT	ac40	5310	Ant2	-6.4	0	-6.4	11	Pass
NVNT	ac40	5310	Sum	-3.34	0	-3.34	8.9	Pass
NVNT	ac40	5510	Ant1	-4.95	0	-4.95	11	Pass
NVNT	ac40	5510	Ant2	-7.3	0	-7.3	11	Pass
NVNT	ac40	5510	Sum	-2.96	0	-2.96	8.9	Pass
NVNT	ac40	5550	Ant1	-7.91	0	-7.91	11	Pass
NVNT	ac40	5550	Ant2	-5.61	0	-5.61	11	Pass
NVNT	ac40	5550	Sum	-3.6	0	-3.6	8.9	Pass
NVNT	ac40	5590	Ant1	-6.1	0	-6.1	11	Pass
NVNT	ac40	5590	Ant2	-8.69	0	-8.69	11	Pass
NVNT	ac40	5590	Sum	-4.19	0	-4.19	8.9	Pass
NVNT	ac40	5670	Ant1	-6.89	0	-6.89	11	Pass
NVNT	ac40	5670	Ant2	-9.78	0	-9.78	11	Pass
NVNT	ac40	5670	Sum	-5.09	0	-5.09	8.9	Pass
NVNT	ac40	5755	Ant1	-9.73	0	-9.73	30	Pass
NVNT	ac40	5755	Ant2	-8.37	0	-8.37	30	Pass
NVNT	ac40	5755	Sum	-5.99	0	-5.99	27.9	Pass
NVNT	ac40	5795	Ant1	-9.15	0	-9.15	30	Pass
NVNT	ac40	5795	Ant2	-7.8	0	-7.8	30	Pass
NVNT	ac40	5795	Sum	-5.41	0	-5.41	27.9	Pass
NVNT	ac80	5210	Ant1	-7.9	0.15	-7.75	11	Pass
NVNT	ac80	5210	Ant2	-6.98	0.15	-6.83	11	Pass
NVNT	ac80	5210	Sum	-4.41	0.15	-4.26	8.9	Pass
NVNT	ac80	5290	Ant1	-10.39	0.15	-10.24	11	Pass
NVNT	ac80	5290	Ant2	-10.93	0.15	-10.78	11	Pass
NVNT	ac80	5290	Sum	-7.64	0.15	-7.49	8.9	Pass
NVNT	ac80	5530	Ant1	-9.91	0.14	-9.77	11	Pass
NVNT	ac80	5530	Ant2	-12.82	0.14	-12.68	11	Pass
NVNT	ac80	5530	Sum	-8.12	0.14	-7.98	8.9	Pass
NVNT	ac80	5610	Ant1	-10.44	0.15	-10.29	11	Pass
NVNT	ac80	5610	Ant2	-9.98	0.15	-9.83	11	Pass
NVNT	ac80	5610	Sum	-7.19	0.15	-7.04	8.9	Pass
NVNT	ac80	5775	Ant1	-13.25	0.15	-13.1	30	Pass
NVNT	ac80	5775	Ant2	-12.22	0.15	-12.07	30	Pass
NVNT	ac80	5775	Sum	-9.69	0.15	-9.54	27.9	Pass

Test Graphs
PSD NVNT a 5180MHz Ant1

TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600



PSD NVNT a 5180MHz Ant2

PSD NVNT a 5200MHz Ant1



PSD NVNT a 5200MHz Ant2

PSD NVNT a 5240MHz Ant1



PSD NVNT a 5240MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT a 5260MHz Ant1



PSD NVNT a 5260MHz Ant2



PSD NVNT a 5300MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT a 5300MHz Ant2



PSD NVNT a 5320MHz Ant1



PSD NVNT a 5320MHz Ant2



PSD NVNT a 5500MHz Ant1



PSD NVNT a 5500MHz Ant2



PSD NVNT a 5540MHz Ant1



PSD NVNT a 5540MHz Ant2



PSD NVNT a 5580MHz Ant1



PSD NVNT a 5580MHz Ant2



PSD NVNT a 5660MHz Ant1



PSD NVNT a 5660MHz Ant2



PSD NVNT a 5680MHz Ant1



PSD NVNT a 5680MHz Ant2



PSD NVNT a 5700MHz Ant1



PSD NVNT a 5700MHz Ant2



PSD NVNT a 5745MHz Ant1



PSD NVNT a 5745MHz Ant2



PSD NVNT a 5785MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT a 5785MHz Ant2



PSD NVNT a 5825MHz Ant1



PSD NVNT a 5825MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n20 5180MHz Ant1



PSD NVNT n20 5180MHz Ant2



PSD NVNT n20 5200MHz Ant1



PSD NVNT n20 5200MHz Ant2



PSD NVNT n20 5240MHz Ant1



PSD NVNT n20 5240MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n20 5260MHz Ant1



PSD NVNT n20 5260MHz Ant2



PSD NVNT n20 5300MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n20 5300MHz Ant2



PSD NVNT n20 5320MHz Ant1



PSD NVNT n20 5320MHz Ant2



PSD NVNT n20 5500MHz Ant1



PSD NVNT n20 5500MHz Ant2

PSD NVNT n20 5540MHz Ant1



PSD NVNT n20 5540MHz Ant2



PSD NVNT n20 5580MHz Ant1



PSD NVNT n20 5580MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n20 5660MHz Ant1



PSD NVNT n20 5660MHz Ant2



PSD NVNT n20 5680MHz Ant1



PSD NVNT n20 5680MHz Ant2



PSD NVNT n20 5700MHz Ant1



PSD NVNT n20 5700MHz Ant2



PSD NVNT n20 5745MHz Ant1



PSD NVNT n20 5745MHz Ant2



PSD NVNT n20 5785MHz Ant1

TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n20 5785MHz Ant2



PSD NVNT n20 5825MHz Ant1



PSD NVNT n20 5825MHz Ant2



PSD NVNT n40 5190MHz Ant1



PSD NVNT n40 5190MHz Ant2



PSD NVNT n40 5230MHz Ant1



PSD NVNT n40 5230MHz Ant2



PSD NVNT n40 5270MHz Ant1

PSD NVNT n40 5270MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n40 5310MHz Ant1



PSD NVNT n40 5310MHz Ant2



PSD NVNT n40 5510MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n40 5510MHz Ant2



PSD NVNT n40 5550MHz Ant1



PSD NVNT n40 5550MHz Ant2



PSD NVNT n40 5590MHz Ant1



PSD NVNT n40 5590MHz Ant2



PSD NVNT n40 5670MHz Ant1



PSD NVNT n40 5670MHz Ant2

TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n40 5755MHz Ant1



PSD NVNT n40 5755MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT n40 5795MHz Ant1



PSD NVNT n40 5795MHz Ant2



PSD NVNT ac20 5180MHz Ant1



PSD NVNT ac20 5180MHz Ant2



PSD NVNT ac20 5200MHz Ant1



PSD NVNT ac20 5200MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5240MHz Ant1



PSD NVNT ac20 5240MHz Ant2



PSD NVNT ac20 5260MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5260MHz Ant2



PSD NVNT ac20 5300MHz Ant1



PSD NVNT ac20 5300MHz Ant2



PSD NVNT ac20 5320MHz Ant1



PSD NVNT ac20 5320MHz Ant2



PSD NVNT ac20 5500MHz Ant1



PSD NVNT ac20 5500MHz Ant2



PSD NVNT ac20 5540MHz Ant1



PSD NVNT ac20 5540MHz Ant2



PSD NVNT ac20 5580MHz Ant1

TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600



PSD NVNT ac20 5580MHz Ant2



PSD NVNT ac20 5660MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5660MHz Ant2



PSD NVNT ac20 5680MHz Ant1



PSD NVNT ac20 5680MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5700MHz Ant1



PSD NVNT ac20 5700MHz Ant2



PSD NVNT ac20 5745MHz Ant1



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5745MHz Ant2



PSD NVNT ac20 5785MHz Ant1

PSD NVNT ac20 5785MHz Ant2



TÜV SÜD Certification and Testing (China) Co., Ltd. Shanghai Branch
3-13, No.151, Heng Tong Road, Shanghai, 200070, P.R. China
Phone: +86 21 61410123, Fax:+86 21 61408600

PSD NVNT ac20 5825MHz Ant1



PSD NVNT ac20 5825MHz Ant2



PSD NVNT ac40 5190MHz Ant1



PSD NVNT ac40 5190MHz Ant2



PSD NVNT ac40 5230MHz Ant1



PSD NVNT ac40 5230MHz Ant2