


Get To Know Your Mobile WiFi

- About Mobile WiFi



1. Power Button
2. *Microphone
3. Forced Reset Button
4. Type-C USB interface
5. Display screen and Touch screen
6. *Speaker
7. *Microphone
8. Indicator Light
10. AI Smart Button/WPS Button
11. SIM Card Slot
12. Device Label



1. Network Signal Status
2. WLAN WiFi Status
3. Status Code
4. SIM Card Status (Physical SIM Mode)
5. Bluetooth
6. GPS
7. Battery Level
8. Battery Status
9. Menu

1. Buttons

- 1) Power Button: Long press the Power Button for more than 3 seconds to

power on/off the device;

Short press to turn the screen on or off.

- 2) AI Smart Button : Short press to turn on the screen. Short press again to turn on the AI.
- 3) Forced Reset Button : Short press to force restart and restore to factory settings. Long press for more than 8 seconds to force power off. (Warning: Please do not press the Forced Reset Button without customer service support.)
- 4) Screen Lock: After 60 seconds without use, the device screen will lock. After 90 seconds without use, the screen will turn off. To lock and turn off the screen, just short press the power button.
- 5) Unlock Screen: Short press the power button to turn on and unlock the screen.

2. Indicator Light Description

Power On Status

Pulsing Red Light	Charging , Low Battery
Pulsing Yellow Light	Charging , Medium Battery
Pulsing Green Light	Charging , High Battery
Continuous Green Light	Charging Completed
Flashing Red Light	Low Battery
Flashing Blue Light	No network
Continuous Blue Light	Normal network

Power Off Status

Pulsing Red Light	Charging , Low Battery
Pulsing Yellow Light	Charging , Medium Battery
Pulsing Green Light	Charging , High Battery
Continuous Green Light	ChargingCompleted

System Status

Continuous Green Light	System Starting Up
Pulsing Yellow Light	SoftwareUpgrade With System Start-up
Pulsing Red Ligh	System Shutdown

3. How to connect a device to yourMobile WiFiNetwork

1) WiFi Network Manual Connection

- a) Find the SSID and KEY displayed on the bottom label of the Mobile WiFi device
- b) Enter the SSID and KEY found on the network connection of your phone or other device you want to connect to successfully connect to the network.

Note: If the SSID and KEY displayed on the bottom label of the device are worn off and cannot be viewed clearly, you can start the Mobile WiFidevice and view it in "Home"-> "Network"-> "WLAN"

2). Code ScanConnection (Camera Scanning / Wechat Scanning)

- a) Start up yourMobile WiFidevice and enter the homescreen
- b) Click the "I want to connect " button at the bottom right of the screen to enter the code scanning page
- c) Open your phone or other device's camera scanner or WeChat to scan the corresponding QR code
- d) After the scan is completed, your phone or other device will automatically connect to the network.

Note: WeChat's scan code function can also be used to scan the Ucode QR code on the label on the back of the Mobile WiFidevice

3).NFC Touch Connection

- a) Turn on the NFC function of your phone or other device you want to connect
- b) Hold your phone or otherdevice to the front bottom area of the Mobile WiFidevice
- c) After the connection prompt pops up on your phone or other device, click

"Connect" to automatically connect.

Note: This feature is only available on Android devices

4). WPS One-click Connection

a) Turn on the "WPS" function in the settings of your phone or other device you want to connect.

b) Click the "I want to connect " button at the bottom right of Mobile WiFi device's screen to enter the connection mode selection page

c) Select "WPS connection" to enter the WPS network operation page, and click

the " " button to activate the WPS network function of Mobile WiFi device

d) Your phone or other device should automatically find the network. After the confirmation prompt pops up on your phone or other device, click "OK" to connect to the network.

Note: i) This feature is only available on Android devices

4. Use of SIM card slot

1) Mobile WiFi both support "Physical SIM "mode and "Virtual SIM "mode. You can

change the setting by navigating to "Home"-> "Network" "-> " SIM Card Mode ".

2) In the " Physical SIM " mode, a SIM card must be inserted to use the Mobile WiFi device. Some SIM cards also need an APN to be setup, which should be setup on the WebUI or App. The external card slot does not support switching SIM cards when the Mobile WiFi device is on. If you need to use a SIM card, restart the Mobile WiFi device after inserting or extracting an external SIM card.

3) In the "Virtual SIM "mode, there is no need to insert a SIM card into the external card slot. You can purchase a data package through the UROCOMM App, and you can connect to a local network by turning on the Mobile WiFi device when you arrive at your destination.

5. Device Management

1) Scan the QR code below to download the Urocomm app. With the app you can easily buy data packages, manage your data, change passwords, set up your device, restart your device, and more.



6. About WebUI– Change your settings though your web browser

- 1) Connect to the WLAN wifi network of your mobile phone or PC device using Mobile WiFi.
- 2) Enter the address "urocomm.info" or "192.168.225.1" in the browser, the default password is: 12345678
- 3) After logging in, you can use the Web Page to change your password and set an APN, etc.

Mobile WiFi Specifications

Product Name	Mobile WiFi
Model	UZ-211-1
Size	86mm*86mm*26mm
Weight	191. 4g
Bands	LTE-TDD: B38/B40/B41
	LTE-FDD: B2/B4/B5/B7/B12/B17/B18
	WCDMA: B2
	GSM: B2/B5
WLAN	Support 2. 4G & 5G
	IEEE 802. 11a/b/g/n/ac
LCD Screen	2. 8 inches

LCD Pixels	240 x 320 pixel
Touch screen	Support
Battery type	Lithium-ion 21700 battery
Cell Norminal Capacity	5000mAh
Cell Rated Capacity	4850mAh
USB Port	Input: Type-C 5V2A
	Output: Type-C 5V1A
Bluetooth	Support (This feature is coming soon)
AI	Alexa
Cloud MiFi	Support
Other functions	GPS, Power bank, Indicator Light, WPS, Interpreter
Working temperature	-10℃-35℃

FAQ

1. How to change the Wi-Fi name and password?

First connect your mobile phone or PC device to your Mobile WiFi WLAN network , and enter "urocomm.info" or 192.168.225.1 in your browser , and enter the password 12345678 to open the administration interface. Here you can change your Wi-Fi name and password. After it has been changed, remember to save it.

Alternatively, you can change the Wi-Fi name and password in the APP.

2. What should I do when my Phone/Tablet can not connect with the device?

- (1) Make sure the Phone/Tablet's WLAN is turned on.
- (2) Refresh the network list, and search for the SSID of the device.
- (3) Make sure to input the correct password.
- (4) Disconnect your device from your current network and then reconnect.

3. What should I do when the device has no internet connection?

(1) Make sure the device status is normal. The signal may be weaker when in airports, mountain areas, high ways, harbors, basements, rural areas and islands.

Please restart and try again after moving to a different location.

(2) If you still can not get an internet connection, please contact us through email : service@urocomm.com

4. What should I do if my device is lost ?

If your device is lost accidentally, please contact customer service to freeze your account in time to avoid additional fees.

5. Why can I not use my device after a SIM card is inserted ?

In some countries when you insert a SIM card, you need to manually set an APN (Access Point Name) . If this is the case, please go to the website: urocomm.info or 192.168.225.1 , and enter the password 12345678; After entering the Web UI, go to Settings" - "Mobile network settings" - "APN" , manually add a network operator APN, and then save the settings.

Warning

- Please only use original accessories provided with purchase. Use of unauthorized chargers or other accessories may cause damage to the device and can result in fire, explosions, or other hazards.

If users of the Mobile WiFi device use a power adapter to charge the Mobile WiFi device, they should purchase a power adapter that meets the requirements of the corresponding safety standards or a power adapter that has obtained the quality and safety certification of the country in which it is used.

- Please keep the device in a dry and cool environment and do not let the device come into contact with water. Extreme high or low-temperatures may cause damage to the device.

- Please do not expose the device to high temperature environments or heating , such as strong sunlight, heaters, microwaves, ovens, or water-heaters etc.

An overheated battery might cause explosion.

- When charging is complete or the device is fully charged, please disconnect the charger from the device and unplug the charger from the power outlet.

- The built-in battery is non-removable. Please do not attempt to change or disassemble the battery by yourself. This may result in damage to the battery or the device. The battery can only be replaced by an official authorized service provider.

- Notice: Using the wrong model of battery may result in an explosion. Please make sure to dispose of used batteries as instructed.

- Device Working Temperature: The device should be kept at a working

temperature of -10°C to 35°C. For the user's safety, please avoid using the device in a high-temperature environment for long periods of time, as this leads a shorter device lifetime. The device will stop charging automatically when the battery temperature reaches 45°C, and shut down automatically when battery temperature is more than 55°C.

- When using an external SIM card, self-cutting SIM cards and non-standard SIM cards can not be used.
- If the Wi-Fi SSID or Key is changed, please use a phone with NFC read/write capability and the Urocomm APP with the same SSID and Key. Otherwise,
- We are only responsible for the function of the device' s official operating system and update system. The use of any other systems or software from unofficial third parties might cause security risks.

FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.
- SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each device are performed in positions and locations as required by the FCC.
- For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 10 mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.
- End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

Caution!

- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

- This device is restricted to indoor use when operating in the 5150-5250MHz frequency range in all EU/EFTA member states and Turkey.

Countries:

(BE/BG/CZ/DK/DE/EE/IE/EL/ES/FR/HR/IT/CY/LV/LT/LU/HU/MT/NL/AT/PL/PT/RO/SI/SK/FI/SE/UK/TR/NO/CH/IS/LI)

EU Regulatory Conformance

Hereby, Beijing ULINK Technology Co., Ltd. declares that this radio equipment type is in compliance with the Directive 2014/53/EU. For the full text of the EU declaration of conformity, visit this website: www.urocomm.com

Notice: The operating temperature of the device between -10°C to 35°C.

This product can be used across EU member states.

Contact

Service Email: service@urocomm.com

Copyright Notice

Beijing Ulink Technology Co., Ltd. reserve the final interpretation of the

UROZETTA trademarks for this product.

For More Surprises:

Please visit www.urocomm.com