

User Manual

Scan QR code to download



Product Structure Diagram:

1. trigger
2. cellphone holder
3. battery bay



Battery Precautions

The battery installation of the toy

1. Please make sure the power supply is switched off
2. Use the "+" screwdriver to loosen the screws on the battery cover, open the battery cover
3. Connect the battery with the gun as the diagram shown on the left
4. Close the battery cover, and tighten the screws



Battery

Unscrewed the battery cover and put the batteries in. Close the battery cover.

Bluetooth connectivity

Turn on the bluetooth and then open the app. Keep holding the trigger for several seconds before connecting successfully.



Super AR

Apoc Wars, robotenemy,zombie
incoming and sky warSuper AR
shooting times come!



Super AR Fun World

Deep sea adventure, fun Math and English casual games Find your favourite one.



Super AR Killer

The first live online comba AR gun game, play together, exciting together!



City Hunter(directionbutton control)

The first to support the arrow keys to control the movement of AR guns, games, a variety of special effects, alerts eyeballs, tanks, aircraft...



Monkey King

The first Parkour game has been fitted with all Super AR gun type.vs

Product name: AR GUN

Model: G20C,G3,G9,G6,G7,G23

Manufacturer: Shenzhen ZY Electronic & Technology Co., Ltd.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.