



SERENE AIR

TRUE WIRELESS EARPHONES




FISHER-FTW645 USER MANUAL

Introduction


For best use of this device we recommend carefully reading this user manual and keeping it for your records.

Package Contents

- a. True Wireless Earbuds
- b. TYPE C charging cable
- c. Instruction manual
- d. Warranty card



FUNCTIONS



MFTC functions

1. Press and hold the MFTC for 5s to power on, or it will power on automatically when take the earbuds out from case.
2. Press and hold the MFTC for 5s to power off, or it will power off automatically when place the earbuds into case.
3. Play/Pause: Short press the MFTC once.
4. Previous/Next songs: Short press L MFTC twice to the previous song, and short press R MFTC twice to next song.
5. Decrease/Increase volume: Short press L MFTC for three times to decrease volume, and short press R MFTC for three times to increase volume.
6. Answer/End a calling: Short press the MFTC once.
7. Reject a calling: Press and hold the MFTC for 1.5s to reject the incoming call.
8. Voice Assistant: Press and hold the MFTC for 3s to activate SIRI.

Indicator lights

1. When charging the earbuds via case: Earbuds will solid red and case will solid blue when charging, and light will goes out after fully charged.
2. When charging the product via charging sources: Earbuds will solid red and case will flash red when charging, and light of earbuds will goes out and case will solid red after fully charged.
3. Earbuds will flash red & blue when power on, and primary earbud will flash red & blue and slave earbud will flash blue twice quickly in every few seconds after both earbuds paired successfully.
4. You can find "FISHER-FTW645" in your BT device listing. When connected with BT device, both earbuds will flash blue once quickly in every few seconds.

FCC Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation. Federal Communications Commission (FCC) Statement This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard. FOR HOME OR OFFICE USE.

Warning

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

Battery Information

- Never use any charger that is damaged.
- Leaving the device in hot or cold places will reduce the capacity and lifetime of the batteries. Optimal temperature for the batteries is between 59°F and 77°F. A device with a hot or cold batteries may not work temporarily, even when the batteries are fully charged.
- Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.



It may damage your hearing if you listen with high volume for a long time.
It is recommended you use the lowest volume possible for listening to music.

All other trademarks are the property of their Respective companies. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.