

User manual

7" Closet Light w/Removable Remote

Remove clear plastic
tab before first use.

Retire la lengüeta de plástico
transparente antes del primer
uso.

Remote operation up to 30ft.

Utilización con el control remoto hasta
30 pies.

When not in use, store the
remote in the wall plate.

To remove remote, run
your finger in the channel
and pry remote from
wall plate.

Cuando no se este utilizando, almacene
el control remoto en la placa de pared.

Para retirar el control remoto, deslice el
dedo por el canal y haga palanca en el
control remoto para separarlo de la
placa de pared.

To activate light, press any auto-off
light buttons to turn on/off The light
will auto-off at the set button 1 min.,
3 min. 5 min. and 15 min.

Para activar la luz, presione cualquiera de los
botones de apagado automático de la luz para
encenderla/apagarla. La luz se apagará
automáticamente en el botón de ajuste de 1 min
3 min, 5 min y 15 min.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.