

- A6S 蓝牙耳机主机
- A6S 耳机充电盒
- Micro 5pin 充电线
- 备用大、小耳帽
- 使用说明书

- 产品型号: A6S
- 蓝牙版本: V5.3
- 电池规格: 耳机3.7V 45mAh; 充电仓3.7V 280mAh
- 支持模式: HFP/HSP/A2DP/AVRCP
- 灵敏度: 105dB±3dB S.P.L at 1KHz
- 信号距离: 10米 (无任何较大障碍物的理想环境中)
- 播放时间: 约 2.5 小时
- 通话时间: 约 3 小时
- 待机时间: 约 80 小时
- 充电时间: 给充电盒充电约1.5小时, 充电盒给耳机充电约1小时
- 充电盒给耳机充电次数: 约2.5次

**1、开机**  
将耳机从充电仓拿出自动开机或长按左右耳机多功能键3秒开机。

将耳机放入充电仓自动关机/长按左右耳机多功能键5秒关机。

当配对成功后，第二次开机时蓝牙耳机优先进入回连状态自动回连已连接过的手机。

在待机状态下，单击左右耳机多功能键均可直接播放音乐，播放时单击左右耳机多功能键均可暂停播放。

播放音乐时长按左耳机多功能键2秒同时响“嘀”一声切换到上一曲，长按右耳机多功能键2秒同时响“嘀”一声切换到下一曲。

双击左耳机多功能键逐级加大音量，双击右耳机多功能键逐级减小音量

手机来电时，单击左右耳机多功能键均可接听电话。

手机通话时，单击左右耳机多功能键均可挂断电话。

手机来电时，长按左右耳机多功能键2秒均可拒接来电。

在待机或者播放音乐时，三击左耳机多功能键即可拨打您通话记录中最后一个拨打过的电话。

三击右耳机多功能键即可启动语音助手进行语音控制手机操作。

当蓝牙耳机电池电量不足时，间隔30秒播放一次电量不足提示音直至耳机低电关机。

The diagram illustrates the components of the device through six separate line drawings. The top-left drawing shows the top of the device with labels for the 'Microphone port' (a small circular opening), the 'LED indicator' (a small rectangular window), and the 'Multi-function button' (a circular button). The top-right drawing shows the side of the device with a label for the 'Charging contact' (a small circular port). The bottom-left drawing shows the device with its lid open, revealing the interior with labels for the 'Charging thimble' (a small circular component) and the 'charging indicator' (a small rectangular window). The bottom-right drawing shows the bottom of the device with a label for the 'USB charging port' (a rectangular port).

- Wireless earphone
- Endurance charging box
- Micro 5pin charging cable
- User's manual
- Earplug silicone cap

- **Product number:** A6S
- **Wireless version:** V5.3
- **Battery specification:** Headset 3.7V/45mAh; Charging box 3.7V/280mAh
- **Support mode:** HFP/HSP/A2DP/AVRCP
- **Sensitivity:** 105dB  $\pm$  3dB S.P.L at 1KHz
- **Transmission distance:** 10 meters (in an ideal environment without any major obstacles)
- **Play time:** About 2.5 hours
- **Call time:** About 3 hours
- **Standby time:** About 80 hours
- **Charging time:** Charge the charging compartment for about 1.5 hours, and charge the headset for about 1 hour
- **Charging box to charge the headset:** About 2.5 times

**1、Boot**  
Take the headset out of the charging compartment and automatically turn it on or press and hold the left and right headset multifunction button for 3 seconds

Put the headset into the charging compartment and turn it off automatically.  
Press and hold the left and right headset multifunction button for 5 seconds  
to shut down.

When the pairing is successful, the Wireless headset preferentially enters the connected state when the second time is turned on, and automatically connects back to the connected mobile phone

In the standby mode, click the left and right earphones multi-function

keys to play music directly. When playing, click the left and right earphones multi-function key to pause playback

When playing music, press and hold the left earphone multi-function button for 2 seconds while ringing “di” to switch to the previous song. Press and hold the right earphone multi-function button for 2 seconds while ringing “di” to switch to the next song

Double-click the left earphone multi-function key to increase the volume step by step, double-click the right earphone multi-function key to gradually decrease the volume

When the mobile phone calls, click the left and right earphones multi-function button to answer the call

When the phone is talking, click the left and right earphones multi-function button to hang up the phone

When the mobile phone calls, long press the left and right headphones multi-function button for 2 seconds to reject the call

While on standby or playing music, you can dial the last call you made in your call history by tapping the left headset multifunction button

Three—click the right headset multi-function button to start Voice Assistant for voice control mobile phone operation

When the battery of the Wireless headset is low, the low battery tone will be played every 30 seconds until the headset is powered off

1. Take out from the charging bin or press and hold the left and right earphones multi-function button for 3 seconds to turn on until the red and blue lights flash alternately, enter the ear search pairing state, enter the ear pair automatic matching, and match the main ear (right ear) The red and blue lights are alternately flashing, the secondary ear is flashing slowly, and the paired ear is successfully played.

2. Start the **Wireless** function of the mobile phone or other devices.  
If it is an Android mobile phone or device, please click the "Search for  
**Wireless device**" option. If it is the IOS system mobile phone or  
device, it will automatically search for the device; when searching for  
the model of the Bluetooth headset after that, click to enter the pairing  
when the pairing is successful, the main (right) earphone will make a  
prompt to connect successfully, and the left and right earphones will  
turn blue and flash slowly, and enter the connection standby state.  
After the pairing is successful, the main ear is the right channel. The  
secondary ear is the left channel.

3.The two earphones can also be paired with the mobile phone separately. The operation method can be operated according to the above step 2 operation method.

1. Plug the Micro USB charging cable into the USB port of the charging compartment and plug in the charger to charge the charging compartment. When the charging power is within the indication range of the corresponding indicator light, the white indicator light of the position flashes once every seconds until When the indicator's power range is full, the indicator light

that is on for the next power range will flash. When all the lights are fully charged, all the indicators will be on.

**2. Charging the headset:** Put the headset into the charging compartment to automatically charge. When charging, the headset indicator is red. When the battery is fully charged, it will be off; the charging compartment white indicator will be on. When the charging compartment is fully charged, the four battery indicator lights are all on. When the charging capacity drops to the corresponding power, the corresponding indicator light goes out. When the earphone is fully charged, the white light of the charging compartment is completely extinguished.

1. Please charge in a safe environment. When charging the charging compartment, please charge the charging compartment separately from the USB charging cable as soon as the charging indicator indicates full power, so as to avoid damage to the charging compartment after a long time of charging.

**2. When playing music, please adjust the music to the appropriate volume to avoid hearing damage at high volume for a long time.**

3. Try to avoid using the headset in a place with interference sources, otherwise it may affect the headphone signal.

**4. Try to avoid using this headset in a corrosive environment to avoid affecting the function of the headset.**

**Tips: When you use this Wireless headset to listen to music or talk please pay attention to adjust the volume properly, so as not to affect the hearing of excessive volume!**

**FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.