

<p>User Manual</p>	<p>1.1 Product Schematic:</p> 	<p>2. Instructions For Use:</p> <ul style="list-style-type: none"> To power on the computer, ensure it's connected to an AC power adapter or the battery level is sufficient. Briefly press the power button to start the computer. During use, pressing the power button briefly will suspend, resume, or shut down the computer, according to the system settings. <p>2.1 Function Keys:</p> <p>This product includes 12 function keys (F1-F12), each assigned to specific operations when used in combination with the "Fn" key. Below is a summary of their functions:</p> <ul style="list-style-type: none"> F1: Enter Sleep Mode F2: Decrease Screen Brightness F3: Increase Screen Brightness F4: Toggle Screen Backlighting F5: Multi-Touchpad Touchpad F6: Multi-Volume Volume F7: Decrease Volume F8: Increase Volume F9: Toggle Keyboard Backlighting F10: Open Screenhot Tool (Equivalent to Win + Shift + S) F11: Open Task Manager (Equivalent to Ctrl + Shift + Esc) F12: EnableDisable Acplane Mode Fn+FN Lock Function Lock Turn on or Off Copilot: Connect to the network and press the copilot key to turn on the Copilot APP 	<p>2.2 Power Supply and Charging:</p> <p>This product can be powered using a lithium battery or an AC power adapter. Before unpacking, connect the AC power adapter to charge the computer before use.</p> <ul style="list-style-type: none"> Lithium batteries do not have a "memory effect", so they can be recharged at any time without waiting for complete discharge. Charging time may be extended if the computer is in use while charging. For faster charging, place the computer in sleep mode or turn it off. When the battery is full, the computer will automatically turn off. The battery will not charge when the power level is 98% or above. When the battery is low, a warning prompt will appear on the screen. The computer will continue to operate until the battery is critically low, at which point it may shut down, potentially causing unsaved data loss. Please charge the battery promptly. Always use the correct power adapter to avoid potential damage to the computer. Lithium batteries contain toxic and harmful substances. Please recycle the battery in accordance with environmental protection regulations and avoid disposing of it improperly to prevent environmental pollution. <p>2.3 Cleaning, Maintenance and Storage:</p> <p>Before cleaning the product, turn off the system and unplug the adapter.</p> <ul style="list-style-type: none"> Clean the product's exterior with a damp cloth and dry it with a soft cloth. Do not use corrosive cleaning liquids. Avoid immersing the product in water or other liquids. After cleaning, store in a dry, flat environment.
---------------------------	--	--	---

<p>3. Safety Guidelines</p> <p>Please read and adhere to the following guidelines to enhance product longevity and ensure safe operation:</p> <ul style="list-style-type: none"> Ensure that the computer's ventilation openings are unobstructed to prevent overheating. Avoid applying excessive pressure to the display. Place the notebook on a stable, level surface. Use a protective bag when transporting the laptop. Do not operate the laptop in harsh environmental conditions. Avoid placing or dropping objects on the laptop. Keep the laptop away from magnetic fields and direct sunlight. Avoid using the laptop in extreme temperatures or exposing it to moisture. Keep the laptop away from heat sources. Do not immerse the laptop in water. Avoid exposing the laptop to dust or corrosive chemicals. Do not force the laptop screen open or use the display to lift the device. Do not spray liquids directly onto the display. Use only original batteries; using non-original or incorrect battery types may pose a risk of explosion. <p>4. Troubles Shooting:</p> <p>If you encounter issues with the laptop, follow these steps:</p> <ol style="list-style-type: none"> Turn off the laptop. Ensure that the AC power adapter is connected to the computer and the power outlet is functioning. Verify that all external devices are properly connected or disconnected them to eliminate potential sources of error. Before restarting the laptop, ensure it has been off for at least 10 seconds, and check if the boot sequence is normal. 	<p>5. Packing List:</p> <p>Your package includes:</p> <ul style="list-style-type: none"> User Manual (x1) Type C PD Adapter (x1) Notebook Computer (x1) <p>6. Safety Information</p> <p>Please carefully review this safety information to ensure safe use of your device:</p> <ul style="list-style-type: none"> Child Safety: Exercise caution when children are near the device. The device contains small, detachable parts that could pose a choking hazard. Hearing Protection: Avoid prolonged exposure to high volumes when using headphones, as this may lead to hearing damage. It is recommended to use the lowest possible volume and limit extended listening sessions. Safe Driving: For your safety, do not use the device while driving. Maintaining full attention on the road is crucial to minimize the risk of accidents. Air Travel Compliance: Adhere to airline regulations regarding the use of electronic devices. Most airlines require devices to be turned off during takeoff and landing. Fire Safety: To reduce the risk of fire, keep the device away from heat sources and flammable materials, particularly during charging. Liquid Exposure: Avoid contact between the device and liquids. Water damage can be permanent and may render the device irreparable. Battery and Charger Care: Do not attempt to dismantle or destroy batteries or chargers. Avoid using damaged components, and keep batteries away from magnetic objects to prevent short circuits. Do not expose batteries to extreme temperatures(lower than 0 °C, above 40 °C). <p>Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.</p> <p>FCC Compliance Statement:</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>RF Exposure Information</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 6cm between the radiator and your body.</p>		
---	--	--	--