

材质: 70G 彩色书纸


size: 展开229\*133.35mm

折叠57.15\*133.35mm



## Product Specs

- USB-C Input: 5V/3A, 9V/2A
- USB-C Output: 5V/3A, 9V/2.22A, 12V/1.67A
- USB-A Output: 5V/3A, 9V/2A, 12V/1.5A
- Wireless Output: 5W/7.5W/15W (max)
- Battery capacity: 10000mAh



## Product Overview

1. USB-A port
2. USB-C port
3. Digital battery display
4. Magnetic charging area
5. Power button

## How To Use

- To view the battery percentage of the power bank, press the power button and view the digital display.
- To turn off the power bank, quickly double press the power button.
- Your device will continue to charge if the power is not at 100%
- To recharge the power bank, plug one end of the provided charging cable into the power bank and the other end into a proper power source.
- To charge your phone, plug one end of the built in USB-C cable into your phone and check to see that the power is on.
- Alternatively, place the back of your phone on the wireless charging surface of the power bank.
- To charge your earbuds, press the power button to turn the power bank on and place your earbuds on the wireless charging surface.
- To light up your logo, press the power button.
- To turn off the light, press and hold the power button for 3 seconds.

## IMPORTANT SAFETY INSTRUCTIONS

**WARNING:** When using this product, basic precautions should always be followed.

Read instructions before use.

Never store product in temperatures below 32°F (0°C) or above 104°F (40°C).

Do not over charge your device with the power bank. The power bank may become hot with excessive use.

Do not expose the power bank to moisture or extreme heat.

When charging, the power bank may feel warm, this is a normal operating condition and should not be cause for concern.

To avoid risk of fire or injury, only use the charging cable provided to charge the power bank.

Do not use the power bank if damaged or modified.

Do not disassemble the power bank.

Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.

Switch off the power bank when not in use.

Do not dispose of power bank in heat or fire.

To reduce the risk of injury, close supervision is necessary when power bank is used near or by children.

Attachments on the back of your phone or some phone cases can impede the charging of your device. Please remove these before using the wireless charger on the power bank.

DISPOSAL INFORMATION FOR USER:

Recycle according to local recycling and environmental regulations.

## FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Origaudio

1770 South 5350 West Suite 100

Salt Lake City, UT 84104 USA

(801) 727 - 1400

[www.hpgbrands.com/origaudio](http://www.hpgbrands.com/origaudio)