

User Manual

1:Product core is the Bluetooth Low Energy Chip CC2541

Bluetooth version is V4.1, Bluetooth Low Energy.

2:Test APP home page shows: Mac, connect status, version, power percent, work mode, unlocking times etc.

Common and customized testing alternative manual for reference:

Common neutral test: install NOKELOCK Bluetooth testing APP → turn on phone's bluetooth and GPS location function→ mobile phone close to the lock→ Search mac and choose the nearest one (<-40) → click the Mac. To enter→ click Unlock button after the device automatically read version, power percent→ unlock and lock about 10 times, and status upload normally.

Customized test (change key & bind): install NOKELOCK testing APP → turn on phone's bluetooth and GPS location function→ enter testing page→ click Scan button to scan QR code→ Read key and unlock automatically after APP shows power percent and version.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation..

Any changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2ANDZ-S02B01