

User manual

Model: TBMSL01

Features:

- Bluetooth® Speaker + Internal Power Bank
- LED Flashlight with SOS Mode
- Hands-Free Phone Calls w/ Built-In Microphone
- Easily Mounts to your Bike's Handlebars

Contents:

- Light, Speaker + Power Bank
- USB Power Cable
- Handlebar Mount
- Instructions

Specifications:

Bluetooth® DID: D031771	Working Distance: 32ft
Bluetooth® QDID: 85539	Rated Power: 3W
Bluetooth® Standard: V2.1+EDR	Power Bank Capacity: 2000mAh
Bluetooth® Agreement: A2 DP	FM Radio: 88-108MHz
FCC ID: 2ANFQ-TBMSL01	Continuous Light: 5-6 hours (full charge)
Model #: RDA5856L	Charging Time: 4-5 hours
Output: 5V/1A Input: 5V/1A	Music Play Time: 8-12 hours

Do not use in wet environments. Colors & contents may vary from what is shown.
Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

INSTRUCTIONS:

1. Long press of power key to turn ON/OFF.
2. Short press of power key adjusts functions: play/pause/answer/hang up the phone.
3. Short press 2x of power button for switches modes.
4. Short press of plus/minus button changes radio station.
5. Long press of the plus key increases volume.
7. Long press of the minus key decreases volume.
8. Short press of the plus/minus key changes the song.
9. Press flashlight power button to turn ON/OFF.
10. While the flashlight is ON, press and hold the button to enable SOS mode.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.