

# *Function Description of the Control Board*

## **I. Square Board**

### **Button Functions**

1. In standby mode, short-press the button, and the indicator light will show the current power level.
2. Long-press the button for 3 seconds to power on; the device will default to the low gear after power-on.
3. Short-press the button after power-on to switch gears.

### **LED Indicator Functions**

1. In heating state:
  1. One LED on indicates low gear.
  2. Two LEDs on indicate medium gear.
  3. Three LEDs on indicate high gear.
2. Power level indication:
  1. One LED on indicates the power level is below 50%.
  2. Two LEDs on indicate the power level is between 51% and 90%.
  3. Three LEDs on indicate the power level is above 90%.

### **Heating Function**

1. Three-gear heating.

### **Wireless Communication**

1. Receive commands from the host computer.
2. Transmit back status information and power level.

## FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference.
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.