

CONTENTS	
QUICK START .....	4-6
WARNING OF LOW BATTERY POWER .....	7
COMPUTER SETUP .....	7-12
WORK WITH PHONES SETUP .....	13-14
MULTIPLE MICROPHONES UESD .....	15
RESTORE TO FACTORY SETTINGS .....	16-17
CONTACT US	

**Get Social:** Facebook page:<http://bit.ly/FifinePage>

**Contact Info:** E-mail:[web@fifine.cc](mailto:web@fifine.cc)

Please take a few minutes to watch the video before you start using the microphone.


**Operation video:**<http://bit.ly/k031bproblemsolving>

More product inquiries can be found on the website.

**Company Website:**<https://fifinemicrophone.com/>

## WARRANTY




- Easily get a 2-year extended warranty with online registration within 90 days of purchase.
1. Input the link : <https://fifinemicrophone.com>
  2. Please roll down to the bottom of the page, fill in E-mail address and submit it.



3. Check your inbox or spam to confirm subscription email.
4. After you click the button "Subscribe me to the list"and next "manage your preferences" to finish registration, tell us the model you are interested, we will send you the the promo info/discount code and 2-year warranty code as well.
- PS: If you cannot update your preferences, just re-do the subscription process.

## WHAT'S IN THE BOX?


### 1.Microphone




## QUICK START

Follow this example as a typical setup to begin recording vocals:




1. Pls Install the 2AA batteries correctly. (Insert batteries confirming to "+" and "-"). Incorrect installation will result in not working and damage the microphone set.




## TIPS FOR WEARING




## COMPUTER SETUP




If you want to monitor your recording,click Microphone "USB PnP Audio Device". "Properties"- "Listen"-click"listen to this device"- "Apply".No sound can be heard through earphone/speaker, if you don't follow this procedure.NOTE:Click off listen to myself when you are using any recording software or chatting software(Skype).




3. Double click on the "USB PnP Audio Device" icon to open the Microphone Properties window. Select the Levels tab to adjust microphone level (loudness). You may need to come back to this window to read just the level after you begin recording.




4. If you want to output from headphone jack on the microphone. Click "Playback"-choose "USB PnP Audio Device"- right click and choose "Enable".



If you want to output from speaker Connecting to your pc, Click "Playback"-choose "USB PnP Audio Device"- right click and choose "Disable". Meanwhile Enable the "Realtek High Definition Audio".



5. Adjust the output volume. Click the specific output device - "Properties" - "Levels" - drag progress bar to control output volume.




**Note(Applicable for MAC and Windows)**


1. If computer prompts that it's unable to identify USB devices, please restart computer and replug the microphone into other USB port.
2. If no sound comes out, please check whether System Sound is mute and whether you have turned volume control to minimum.
3. if mic recognized but not sound out,and your computer runs windows 10, please go to settings>privacy>microphone and click the Allow apps to access the microphone to ON then restart.

## Software Settings

\* For recording, please plug the earphone into the microphone. Then select "USB Audio Device"as the input and output device from the setting of software.(Take the Audacity for example.)



\* Make sure to click off listen to device in your computer system when you are using any recording software,or else you would hear duet of yourself just like too much echo.



## WORK WITH PHONES

### 1.IOS

K031 Works with Apple products(iPhone iPad). Step as below

1. Use a genuine Apple Lighting to USB camera adapter connect with USB receiver to Apple product. Unplug both adapter and the receiver if you want to listen to the playback.


2. Download the available APP from Apple Store, such as Voice Memo and you are ready to go.

Note:Only work with the recording software for recording function.Not apply for online chat purposes (skype or facetime etc)

### 2.Android


K031 Works with Android smartphones. Steps as below.

1. Use a suitable adapter connect with USB receiver to android devices.Unplug both adapter and the receiver if you want to listen to the playback.



\* OTG adapter and Type-c adapter cable is not included in our package.

\* You will need to enable OTG from the phone settings if your phone doesn't supply power for the usb receiver.



\* Pls change your OTG adapter and Type-c adapter cable if the microphone can not be read by your phones.

## SPECIFICATION

**Lavalier / Headset Microphone**

Type: Condenser

Impedance: 1-1.9K

Sensitivity: -44±2dB RL=680 Vs=1.5V (1KHz 0dB=1V/Pa)

Frequency Response: 50-16KHz

Direction: Uni-direction

S/N Ratio: More than 58dB

**Transmitter**

Frequency: 565.000MHz - 584.000MHz

Radio-Frequency Power: 10dBm/10MV

On-off Control: Physical Switch

Power Supply: 2\*AA Batteries

**Receiver**

Frequency: 565.000-584.000MHz

Sensitivity: -95db

S/N Ratio: More than 58dB


Frequency Response: 40Hz-15KHz

## MULTIPLE MICROPHONES USED SIMULTANEOUSLY

When multiple microphones used simultaneously or if there is any interference in your location, please try other available channels by the below procedure:

**Frequency changed setup:**

1. Press and hold the transmitter's on-off button until the Lcd screen is on.



Note: One computer would only recognize one usb microphone, you have to use two separated computers or download specific software if you need to use A and B wireless usb mics simultaneously.

## WIRELESS FREQUENCY AND CHANNEL GUIDE

565.000	566.000	567.000	568.000	569.000	570.000	571.000
572.000	573.000	574.000	575.000	576.000	577.000	578.000
579.000	580.000	581.000	582.000	583.000	584.000	


## RESTORE TO FACTORY SETTINGS

Before enter reset mode,please make sure you've done all the below steps:


1. You have changed with new fresh batteries and you still suffer from interference and disconnection.
2. You have changed the frequency by one click the "SET" button on the top of transmitter,and they doesn't pair with each other successfully whatsoever.
3. If you have multiple K031 and some of microphone set doesn't work. Please enter the reset mode with caution, follow steps as following:
  - 1) Turn off transmitter and unplug the receiver at first.




3) Plug the USB receiver into computer while the screen is flashing with 564.00MHz. The receiver indicator flash for 3 secs and then extinguish.



4) Click "SET" on the top of transmitter to confirm when receiver light is off.



5) The screen of transmitter stop flashing,the frequency of transmitter has been changed from flashing 564.000MHz to other available frequency. The blue indicator of receiver is on and stay on blue light. Transmitter and receiver paired successfully.



Attention: \* 564.000Mhz is a special frequency that will only appear in the reset mode,not included in the regular 20 frequency. \* 566.000MHz is an example ,that could be any of other available 20 frequency.





FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.