



#### FEDERAL COMMUNICATIONS COMMISSION STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

You are cautioned that any change or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment.



# User Manual

Item	Quantity
GoPay K50 Bluetooth Card Reader	1
USB Cable	1
User Manual	1

AGENCY APPROVED



**GoPAY**

K50 Bluetooth Mobile Reader

FCCID:2ANZ7-K50

## Getting Started

1. Download and install the GoPay Bluetooth Client Application, register and login to the GoPay Client on your mobile device.
2. Press the power button for 2 seconds; an audible beep indicates that the reader has been powered on and will flash blue light.
3. Enable Bluetooth from your mobile settings, execute the GoPay Bluetooth Client Application, and it will perform an automatic GoPay Bluetooth Reader ID (Serial Number). Searching and pairing: **(First pairing requires a pairing PIN entry of 1234 as the PIN)**. Upon successful pairing, the blue light will remain lit.
4. Press [Start Transaction] and follow the instructions to complete a transaction.
5. Transaction State:
  - a. Transaction Approval results in a single “Beep”
  - b. Transaction Decline results in a “Beep–Beep”
6. Low Power State: Reader at low power continuously sounds a “Beep–Beep” every second.
7. Charging State:
  - a. Charging via USB cable: Red light flashes
  - b. Complete Charging: Red light remains on
8. Bluetooth Connection:
  - a. Bluetooth disconnected: Blue light flashes
  - b. Bluetooth connected: Blue light remains on
9. Sleep: GoPay Bluetooth Card Reader automatically enters sleep mode after idling for 90 seconds.

## Note:

1. Using the MSR: Swipe the magnetic stripe card with the MagStripe facing the reader and swipe quickly with constant speed (MSR reader supports swipe from both directions).
2. Using the IC Card Reader: Insert the IC Card with the chip facing towards you. DO NOT remove the card before the transaction is completed.

## GoPay Card Reader Specification

1. Supports IC Card; Support 2-track or 3-track MagStripe Card (Bi-directional swiping).
2. Equipped with two-channel Bluetooth module, iOS 4.0 or above; Android 2.1 or above.
3. Equipped with 3.7V, 200mAh, rechargeable lithium-ion battery.
4. Supports charging and low-power state LED indicator.
5. Equipped with Micro USB, used for firmware updates and charging requirements.
6. Input voltage is DC 5 V, 1 A, device can be charged through plug-in or connection to PC.
7. Operational temperature: 0°C ~ 50°C;  
Humidity: 10% ~ 93% (no condensation).
8. Storage temperature: -20°C ~ 70°C;  
Humidity: 5% ~ 95% (no condensation).

## Safety Precautions

1. DO NOT place and/or use the device under extreme and constant sunlight; extremely high temperature; extreme humidity, or an extremely dusty environment.
2. DO NOT insert any abnormal objects into the device; this may lead to severe damage.
3. Using the device under dangerous environments is not suggested.
4. Use a damp cloth to clean the device.
5. Avoid direct contact with liquids.
6. If the device is not functioning, contact your local retailer or customer service department for professional repair. DO NOT attempt to perform repair the device, as the warranty will be voided.

## Installation and Precautions

1. Mobile device unable to detect the GoPay Bluetooth Card Reader:
  - a. Please ensure that the GoPay Bluetooth Card Reader is powered on.
  - b. Please ensure that the Bluetooth is turned on within your mobile device, and that the GoPay Client Application is correctly installed and registered.
  - c. Please check if the device is in low-power mode; if so, please charge the device.
2. Unable to read MSR
  - a. Please check to see if there is a foreign object in MSR slot.
3. Unable to read IC Card
  - a. Please check if the IC card is inserted correctly (chip contact with IC card reader switch); IC card chip facing towards you

## Warranty

1. 12 month warranty started from the original purchase date
2. Damage due to natural disaster; fire; manual change; disassembling; or abnormal use, storage, and maintenance is not cover under warranty
3. Warranty only covers the service for items included in the original package
4. No warranty will be provided without retailers' signature proof or warranty card
5. For detailed service clause, please contact customer support. All rights reserved.