


5000mAh POWER BANK

5000mAh Portable Power Bank with Built-in
Magnetic Charger



WHAT'S INCLUDED:

- 5000mAH Magnetic Wireless Charging Power Bank
- USB-A to USB-C Charging Cable

LED INDICATOR GUIDE:

•	One Light	- 25% charged
• •	Two Lights	- 50% charged
• • •	Three Lights	- 75% charged
• • • •	Four Lights	- 100% charged

CHARGING THE POWER BANK:

- The power bank requires approximately 2-3 hours to fully charge.
- Using the USB charging cable provided, plug the USB-C end into the power bank and the opposite end into a USB power supply of at least DC 5V/2A (not provided).
- The LED light(s) will show the current percentage of power.
- When the power bank is fully charged all 4 LEDs will be fully illuminated.
- When not in use, a fully charged power bank will last a minimum of 6 months. To increase the longevity of your power bank use it regularly and be sure to charge it when it has been depleted. Avoid extreme temperatures, do not leave the power bank in direct sunlight for extended periods.

FRONT

4.65 in

CHARGING YOUR DEVICE:

Wired Charging

- Using the USB charging cable compatible with your device, plug the USB-C end into the charged power bank, and the compatible charging tip into your device.
- The power bank will begin to charge automatically.
- The LED lights will display the amount of charge remaining in the power bank as it charges your device.
- The amount of charges the power bank will provide depends on your device's power needs.

Wireless Charging

- Wireless charging is compatible with iPhone 8 and newer phones as well as other wireless charging enabled devices. Please consult your device's user manual if you are unsure if your device is compatible. Note: Apple Watch® is not compatible with this device.
- Please remove all foreign objects from the wireless charging area before use to ensure safe operation.
- Place a wireless charging enabled device on the wireless charging area.
- The power bank will begin to charge automatically.
- The LED lights will display the amount of charge remaining in the power bank as it charges your device.
- If your device does not begin to charge, try repositioning your device on the wireless charging surface. You may need to remove the case of your device to charge properly.
- Remove your device from the wireless charging area when it is fully charged.
- Note: The Magnetic Ring only works with MagSafe® and magnetic compatible devices, check your devices user manual to ensure compatibility.

SAFETY:

- **WARNING** When using this product, basic precautions should always be followed, including the following:
 - Read all of the instructions before using the product.
 - To reduce the risk of injury, close supervision is necessary when the product is used near children.
 - Do not put fingers or hands into the product.
 - Do not expose power bank to rain or snow.
 - Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
 - Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
 - Have servicing performed by a qualified repair person using only identical replacement parts, this will ensure that the safety of the product is maintained.
 - Do not disassemble the power bank if repair is required. Incorrect assembly may result in a risk of fire or injury to persons.
 - Do not expose to fire or excessive temperature. Exposure to fire or temperature above 212°F (100°C) may cause the power bank to explode.

SAVE THESE INSTRUCTIONS

Model: MC80A; FCC ID: 2AO23-MC80A; USB-C Input: 5V=2.4A; USB-C Output: 5V=2.4A; Wireless Output: 5W/7.5W; Total 12W Max; Battery Capacity: 5000mAh; Made in Vietnam

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

8725 COLUMBINE RD EDEN PRAIRIE, MN 55344-6695, PO Box # 44895. Distributed by ZSOU.

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at support@zsoupower.com

7.5 in

BACK