

Precautions

Read this manual and the following instructions carefully before using the product.



Caution

Safety warning

- This product contains a lithium-polymer battery. Do not give an impact or damage the product.
- · Do not expose the product to the temperature of 50°C (122°F) or higher.
- · Do not disassemble the product, break into pieces, make holes or put in fire or water.
- · Do not touch the product or the charger while charging the product.
- · Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions

Precautions before use

- ·This product may malfunction near an object containing a magnet.
- $\cdot This \, product \, needs \, a \, device \, with \, the \, Phigolf \, application.$
- The figures shown in this manual can be different with the actual product.
- This manual is subject to change without a prior notice for improvement of performance.

Contents of the package









Phigolf Sensor

Micro USB cable

Quick manual

Pouch

Names and functions of the parts





How to use

How to mount

Insert the product into the grip end hole of the swing stick or club. Push the club insert to the end.

*Your swing stick or club may have no or smaller hole in the grip end.



Power on



Press and hold the power button for at least 1 second.

How to charge the battery

Remove the USB cover, connect the USB cable, and connect the other end of the USB cable into a computer or an charger adapter. Charge the battery fully before first use of the product.

Installing the application

Supporting environment

Android 5.0 / iOS 9 or later version

Downloading and installing the application

- 1. Search PHIGOLF in Google Play or Apple Appstore.
- 2. Download and install the app.
- When installation is completed, a PHIGOLF icon appears on the screen of the mobile device.

Connecting the product with the application

Before connecting the application with the mobile device, check if the mobile device supports the Bluetooth communication.

- 1. Switch on the Bluetooth function of the mobile device with the app.
- 2. Start the PHIGOLF app.
- 3. Push the power button on the product.
- 4. The product is automatically recognized by the menu screen of the app.
- Touch the OK button to approve the product, and you can use all the functions of the app.

How to swing

- When the avatar appears on the screen, take the address with the club or the swing stick with the product.
- 2. Direction: Place the direction marker (arrow) on the product to 12 O'clock.



- 3. Hold the address position until the Ready sign appears on the app.
- 4. Swing the club when the Ready sign appears. The Ready sign appears on the app screen with a tone, and the status LED of the product maintains the On position. (During Ready, even a small practice swing can be recognized as an actual swing.)
- If a swing is not recognized, a retry sign appears on the app screen. Take the address, and swing the club following the Ready sign.

Warranty

The warranty period is 1 year from the date of purchase of the product. No warranty is provided for a damage caused by the user, whether such damage is intentional or not, or force majeure.

To use the warranty service, send us the defective product with the receipt issued by the original seller by mail. For the defect within the category of warranty, the product will be repaired, replaced or refunded.

If you cannot contact the original seller, you can visit the website of PhigoIf Networks (www.phigoIf.com) to receive the warranty service.

Label in compliance with the Quality Control and Safety Management Act



0	
Device name	Specific low power wireless device
Date of production	Indicated separately
Manufacturer/Country of origin	Ubitech / Korea
Authentication code	MSIP-CRS-gin-PHG-100
Frequency	2400~2483.5 MHz
Electric field strength	1mW or lower
USB nower sunnly	DC 5V / 300mA



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential interference.

installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receive
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/ IV technical for help.
- orny sinciaca interiace cause sirouta be ase

Finally, any changes or modifications to the equipment by the use not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Information

This equipment complies with FCC RF exposure limit requirements set for in an uncontrolled environment



CAUTION: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- Changes and modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the eauipment.







