

Instructions

Product Name: Fingerprint padlock

Model No.: HTH-DB

1. Registration of fingerprints

1.1 Each new padlock is in the initial state and can be opened with any fingerprint.

When the padlock is in the unlocked state, put your finger press on the fingerprint sensor for 3 seconds, the indicator light is on and the fingerprint EDIT MODE is started.




1.2 Put your fingers on the fingerprint collector, the indicator lights flicker and turn off, then lift your fingers and press the fingerprint collector again, the indicator lights flicker and turn off, repeat this process for three times. If registration is successful, the indicator light will be on for a whole second; if registration is failed, the light will flicker two times.


PS : The initial state will be over after the first fingerprint is registered.

2.Work with iPhone


2.1 Start Bluetooth,run Homekit App through iPhone.




2.2 Select 'Add Accessory' button , Scan the Homekit code in the box lid.



or manually enter the code.




2.3 Run HomeKit App, Click the lock in your device list to unlock your padlock and click again to lock it.



3. Restore factory settings

When the padlock is in the unlocked state, insert the reset pin into the resetting hole on the bottom of the padlock for 3 seconds, the indicator light is on and the Restore Factory Setting MODE is started.



Put your fingers on the fingerprint collector which have been registered. Then all the data will be deleted.

4.Charging

Open the plug at the bottom of the padlock then charge the lock with a USB joint and do not over charge.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.