



QUICK START GUIDE

What's included



What's required



1 DOWNLOAD THE APP


Download the Deep Sentinel app from the App Store® or Google Play™. Open the app and follow the instructions.



2 SELECT A PLACE FOR THE HUB


Consider the following when evaluating Hub placement:

- Put the Hub in a central location in your home
- The Hub must be connected by an Ethernet Cable to your WiFi Router
- Put the Hub in a raised position (not on the floor)
- Avoid large appliances and sources of signal interference



3 CONNECT THE HUB

- Connect the Hub to an available outlet with the included Power Supply
- Connect the Hub to the Router or Ethernet Switch with the included Ethernet Cable




The Hub light will turn on solid green. This might take a minute or two.



4 CHARGE THE SPARE BATTERY


- Remove the lid from the top of the Hub
- Match the included spare battery. The Hub light will blink 3 times when charging starts
- Put the lid back onto the Hub



5 CONNECT THE CAMERA

- Twist the battery door anti-clockwise and open the compartment
- Insert a battery with the terminals facing into the compartment
- Close the battery compartment and turn clockwise to lock
- When prompted by the app, press the Camera button



When closing the battery door, make sure the 2 indentations located on the door and camera align to create the weatherproof seal.



7 CAMERA POSITIONING GUIDELINES


Aim for side-to-side traffic.
Place the Camera so that side-to-side traffic crosses the field of view. The motion sensor is faster and more sensitive to side-to-side motion.

Recommended height and angle




6 VERIFY SIGNAL STRENGTH

- Go outside and hold the Camera where you plan to mount it
- Use the app to check the number of bars in the signal strength icon
- If the signal is weak, try different positions
- Sometimes moving by a few feet can improve the signal



8 INSTALL THE MOUNT


Slide open to reveal the mounting hole.



PN: 752-00002 rev. 01

9 ATTACH THE CAMERA

- Slide the Camera into the mount until it clicks into position
- Check the orientation of the Camera, the lens should be at the bottom and the speaker at the top
- When prompted, use the app to adjust the protection zone



10 REQUEST FOR RESPONSE

To test your connection with a Live Sentinel Guard, make this signal with your hands in front of the Camera and wait for a response.

