





# eufyCam E40 Add-On

## Quick Start Guide



For Video / User Guide / Support

### What's in the Box




### Getting Started


#### 1 Download eufy App



#### 2 Add eufyCam E40 Add-On



#### 3 Fully Charge the Camera





Anker Innovations Limited. All rights reserved,  
registered in the United States and other countries.

Anker Innovations Limited  
Unit 56, 8th Floor, Tower 2, Admiralty Centre, 18  
Harcourt Road, Hong Kong




Model: T8144  
51005005493\_V1

PAP 22  
Raccolta Carta

#### 4 Recheck in the App

Check before installation:

- Strong Wi-Fi signal
- Smooth live streaming




#### 5 Get the Items Ready

For camera installation



Tools you will need




## Mounting Your eufyCam


### 1 Choose a Location

Best location recommended


- Height of 2-3 m
- Field of view of 10 m
- **100% of solar panel area receives sunlight**
- Strong Wi-Fi signal



### 2 Position & Drill Holes




①  
Position




②  
Drill holes

### 3 Insert Anchors





(for hard wall)




(skip for wooden wall)

### 4 Install Mounting Base



①



Take it apart



②


Install the base

### 5 Mount the Camera



①

Tighten the small knob



②


Tighten the large knob

### 6 Adjust the Camera Field of View



①

Remove the protective film



②

Get an optimal angle when viewing the live stream in the app





③

Tighten the large knob

## Find Out More

Congratulations!  
You are now all set to use your eufyCam!  
Please explore more in the eufy app.





Fusion Link serves as an expansion port for future eufy accessories, including support for long-range image transmission. Learn more at [support.eufy.com](https://support.eufy.com)

## Important Safety Instructions

- The suitable temperature for T8144 and accessories is -20°C to 50°C (-4°F to 122°F) (USB charging temperature is 0°C to 45°C (32°F to 113°F)).
- Unless specifically indicated that it is safe to do so in the user guide or instruction manual, do not use this device in an environment that exceeds the recommended low or high temperature.
- Unless specifically indicated that it is safe to do so in the user guide or instruction manual, avoid exposing your device to direct sunshine or excessively wet environments.
- When charging, please place the device in an environment that has a normal room temperature and good ventilation.
- Do not use the product in any way other than described herein in order to avoid personal injury or property damage.
- User should comply with the laws and regulations of the corresponding countries and regions where the equipment is located (used), abide by professional ethics, pay attention to safety obligations, and strictly prohibit the use of our products or equipment for any illegal purposes. Our company will not be responsible for any violators' legal liability under any circumstances.

### Warning

- Replacing a battery with an incorrect type may bypass safeguards and create danger;
- Disposal of a battery in a fire or other source of significant heat, or by crushing, or cutting, may result in an explosion as well as leakage

- of flammable liquids and gases;
- Leaving a battery in an extremely hot environment may result in an explosion as well as leakage of flammable liquids and gases;
- A battery subjected to extremely low air pressure may result in an explosion as well as leakage of flammable liquids and gases.

## Notice

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult the dealer or an experienced radio/TV technician for help.

### FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

The following importer is the responsible party  
Company Name: POWER MOBILE LIFE, LLC  
Address: 10800 NE 8TH ST #900, BELLEVUE, WA, 98004, UNITED STATES  
Telephone:1-800-988-7973

### IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the

device.

This Class B digital apparatus complies with Canadian ICES-003.

### IC RF Statement

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.

#### Déclaration IC

Cet appareil est conforme à la ou aux norme(s) RSS exemptes de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) l'appareil nedit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil numérique de Classe B est conforme à la norme NMB-003 du Canada.

#### Déclaration IC RF

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps pour garantir la conformité aux exigences

d'exposition aux RF.

## Customer Service



12-month limited warranty



support@eufy.com  
service@myeufy.com.au



(US/CA) +1 (800) 988 7973  
(AU) +61 3 8331 4800