



ITEM NO.UD2169A Manual

Thanks for your using.In order to know about our products better,please read this manual carefully before using

Note

- Electronic control product
This product is suitable for children aged Three or above.Please pay attention to and prevent electric shock when using electronic products.
- Please use the product under the supervision of adults.
Warning:Please do not disassemble or modify this product, or it may not function properly due to any change.

Note


- 1.The remote control require 2 1.5V AA non-rechargeable batteries.
- 2.The car requires one piece of 4.8V AA rechargeable battery.
- 3.Pay attention to the polarities and types when loading batteries.
- 4.Non-rechargeable batteries are not to be recharged.
- 5.Product contact for 30 minutes
- 6.The supply terminals are not to be short-circuited.
- 7.Adult supervision required when charging.
- 8.Check the cord,plug,power switch,enclosure and other parts regularly.
Please do not use them if any damages.
- 9.When the car is not in use, please make sure that the power switch is "OFF"and remove the batteries in the car body and remote control.
- 10.This product is made of plastic and metals,avoid immersing the batteries in the water.
- 11.There may be little difference between object and picture,please adhere to the actual product instead.
- 12.The package contains important information,please keep it properly for future reference.

2.4G signal connection introduction


- 1.Place the batteries in the remote control, and the indicator light of remote control starts flashing.Load battery in the car and switch it on, and it begin to signal connect.When the signal connection completed, the indicator light of remote control turn off.Note:If the signal connection failed,please repeat the above operation.
- 2.One remote control used to connect with one car only,when the signal connection is completed,the car drives without any interference.Note: multiple connections at the same time are not allowed.

- 3.When the remote control fail to find the car's 2.4G signal in 1 minute,it will enter to sleep mode(indicator light is off),press any button to exit the sleep mode.
- 4.When match with other same type remote control or car, please turn off the remote control and car.

Product configuration



Part designations



How to install battery

Remote control


- 1.Remove the battery cover of remote control, and load the AA batteries into the battery box according to the polarity indication on the battery box.
- 2.Attach the battery cover.



2X1.5v "AA"

RC car

- 1.Remove the battery cover of the car bottom, connect the rechargeable battery pack to the power socket and put it into the battery box.
- 2.Reattach the battery cover, and fasten it with screwdriver.




(2)

(1)


How to charge battery pack

- 1.The new battery pack need to be charged before use.
- 2.Insert the plug of the battery pack to the port of the USB charging cable, and connect the USB charging cable plug to the socket.
- 3.the charging time is 4-5 hours.The indicator light of the USB charging cable turn red when charging, and turn off when full charged. Do not over charge, it will not change battery capacity limit.
- 4.Check the car, battery, charging cable, plugs and other parts regularly.



How to control the car

- 1.Turn on the car.
- 2.Push the direction lever of the remote control to let the car run forward/backward, or turn left/right.
- 3.When the car is not in use, please turn off the power of the car.
- 4.One key transformation, press the transformation button and the car will transform automatically. (Only one side transform)
- 5.When the driving is ended, turn off the power of the car, and the remote control will enter into sleep mode automatically.



Operation tips

- Please make sure that the power switch is "ON" when the vehicle is being operated. When the power switch is "OFF", the car is turned off.
- When the battery is low, it will affect the left/right turning and slow down forward/backward range.
- The effective control range of the RC car is about 40 meters. The car will stop running or be out of control if beyond this range.

Common fault processing

Problems	Causes	Solutions
The car has no response	1.The remote control fail to connect, or the car is on "OFF" 2.The remote control and remote control car batteries are installed improperly. 3.The power of the rechargeable battery pack is weak.	1.Turn on the car and repeat the operation of signal connection. 2.Install the batteries according to the polarity instructions on the battery box correctly. 3.Please full charge the battery pack.
The car is out of control, or the control range turn short.	1.The batteries of the remote control is low, or the power of the battery pack is weak. 2.There may be interference near the site.	1.Replace with new batteries for the remote control, or charge the battery pack. 2..Replace the battery
Exception protection	1.The car is hindered by external force and the function of the car can not be completed, or the electronic circuit is short-circuited.	1.Turn on the power again, Remote control car power protection.

Instructions


Instructions shall state that battery chargers used with the toy are to be regularly examined for damage to the cord and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

Maintenance instruction

- 1.Do not close to the fire source, and keep away from direct sunlight and high temperature and humidity, such will avoid short-circuit or electrical fire.
- 2.Take out the battery from the car and remote control, and put the car and remote control into the package to avoid the damage when transporting or being in storage.
- 3.Use dry and soft cloth to clean the car.

Warm tips

- When the car moving, please do not touch the wheels of the car, and avoid injury.



Do not play on the road or in dangerous places in case of an accident.

Do not play the car in the sump.

To consumers

- 1.Be careful not to cause damage to the furniture or glass when playing the car in the room.
- 2.Play in the safe outdoor environments, do not play the car on road or in crowd for safety.
- 3.When play the car in the outdoors, please stop playing when hear the thunder.
- 4.Do not reach the rotating wheels to avoid injury. Prevent things like hair and clothes from getting caught in the wheels.
- 5.Do not drive the car toward to people.
- 6.The car is made of complex electronic circuits and electronic components, do not disassemble or modify the circuit board.
- 7.If the car is dirty, please clean it with dry and soft cloth.
- 8.Do not put the toys in the water, otherwise, the electronic parts will be damaged.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.