



Brand name: Shoe Beatz™

How to connect Bluetooth® Wireless technology enabled speaker

- TO TURN ON: Press and hold the power button on the tongue of shoe. You will hear “Power On”. The light will flash red and blue.
- On your device, open settings, and tap the Bluetooth® wireless technology icon to make sure it is switched on.
- Select your speaker from the list. It will show up as “Shoe Beatz”.
- When the connection is made, the light will flash blue.
- You are now ready to hear some beats!
- TO TURN OFF: Press and hold the power button on the tongue of shoe. You will hear “Power Off”.
- If not connected for minutes, the speaker will automatically power off.

Approximate hours the speaker will continuously play from a full charge:

X Hours (need to confirm)

How to charge:

- The speaker is only on the right shoe and is rechargeable using the USB charging cord. (included)
- Lift the hidden flap located under the tongue of shoe and plug the charging cord into the port.
- Once the micro USB is securely plugged into the port, plug the other USB end of the charging cord into a universal USB charger (not included) and connect to an electrical outlet.
- When charging, the light located next to the speaker will be blink red.
- Shoe will fully charge after 3-4 hours. Do not overcharge.
- When light does not turn on by pushing power button, it is time to recharge.

Bluetooth® Wireless technology enabled speaker specs:

Bluetooth® 4.2 Operating Description:

Product: Bluetooth® 4.2

WARNING:

Do not charge for more than 4 hours.

FCC Notices:

Product Name: Shoe Beatz

Model Name: HTR-B1623-B

FCC ID: 2AOPFTERRY201802

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.