



# IP CAMERA User Manual

## Model:WN-US-IPC1080



For product safety and privacy, please kindly change the default account and password before using our product.

## 1.Download "IEye", register and log in

(1)Scan the following QR code with QQ or third-party browse (do not use Wechat to scan)



Android



iOS

Or search directly "IEye" in your App store or google  
Or download from the link <http://www.ihomeapp.cn/>

(2) according to tips, register with your email or phone number, and then log in.

## 2.Add a device

(1)Power on with the device

(2)Wired connection (cell phones and devices must be with the same network/domain)If this device has a RJ45 interface, plug in network cable for configuration. (The router should assign IP addresses automatically using DHCP protocol)


a.Connect with ID number. (ID number is below the QR code pasted onto the device.



I Click "+" to add a device




II Click 'Add online device'



III Input ID and password (Default password is 123456) Add your own device name and save it.

b.Change wired connection into wireless connection

(wifi name and password can not contain Chinese and symbols, and it does not support 5G wifi)



I Click 'Setting' in the home page II Click 'network setting' III Select the wifi you want to connect IV Enter Wifi password. Wifi connection succeeds. Wait for 1 minute and then unplug net cable

## (3)Wireless connection

(wifi name and password can not contain Chinese and symbols, and it does not support 5G wifi)


### a.Smart link



I Click "+" and then "Add new device"



II Click "Smart link"




III Enter Wifi password (Choose the same wifi as your phone)



IV After you hear "di-di-di", click "The next step" (If this device do not have a sound function, enter into the next step directly)




V Waiting for connection



VI Connect successful. For safety reason, please change the default password and name the device. Save it.

## b.AP connection (This function is available for device with AP mode.)



I Press the reset button on the device. Open your mobile phone wifi, connect the camera's AP that begin with GW. AP password is 12345678 (if you not find the AP in your mobile phone, then please reset the camera again) II (Android) open "IEye" APP. The device connect automatically. III (iOS) open "IEye" APP. The device connect automatically.


When AP connection succeeds, you can transfer into Wifi connection mode

## 3.Delete a New Device

Android: long press the camera that you want to delete on the mobile phone, Click confirm to delete it.  
IOS:sliding left to delete the camera

## 4.Function application and General settings

(1)SD card Video Settings (the camera insert SD card then can use like this)



I enter the main interface, click the setting II click record settings III There are three record modes optional: Record manually, Record alarm, Record timer. "Record manually" means uninterrupted recording. Click "Record switch" to set it. IV "Record alarm" means recording when the device is alarming. Choosing different time period accordingly. Click "Pre-record" to set it V "Record timer" means timing recording. Choosing different time period to record. Click "Pre-record" to set it VI The capacity can be viewed at the bottom of the interface. Click format to format the SD card.


## 2.Common operations and Setting

### (1)Device list interface




+ Add new device  
- Edit device name  
- Modify device password (Initial password: 123456)  
- Defense (Click it to achieve motion detection)  
- Playback (Click it to see the playback)  
- Settings (Click it to enter the setting page)

### (2)Monitoring interface




Setting (Click it to enter the setting page)  
Preset position  
Video display mode  
Patrol direction  
Record  
Click to talk  
Snapshot  
Full screen mode  
Outspeaker

## 3.Screen and sound Setting




Adjust the volume  
Adjust the motion detection sensitivity  
Click to adjust direction of video displaying

#### 4.Alarm settings




#### 5.Other settings

##### (1)Device Settings page



##### (2)Device List page



#### Q&A

##### 1. General issues

Q:Why can not your device connect with wifi?

A:Check the password and input again.If it does not work, try to reset the device.This device recently can only support 2.4G Wifi.(Not support 5G)

Q:Why can not the device connect successful even Wifi is very good ?

A: The name of wifi and password cannot contain Chinese letters or symbols.It should be numbers or mixed English letters.

Q: What does the display of "Weak password"?

A: Default password is 123456, change password to ensure privacy safety.

Q: Why can not hear"Di" "Di"?

A: Reset the device.Wait for 1 min, And then try to connect again

Q:The device is off-line?

A:Please ensure the device connect with Wifi successfully or not(check Network indicator light is on or not.If this light is on, pull down to refresh . Please check mobile network condition if you failed to refresh. If this light is not on, please check your network. Remark: device has to be connect morden through wireless or wire, can not connect morden directly.

Q: ! mark appears in device list?

A:Firstly, check Network indicator light is on.If not,please check network and also ensure the password is correct.

Q: Why does the device make warning tone "WONG" "WONG"after successful connection?

A: Since it is a wireless transferring between device and mobile.Radio noise is natural to be there if the device is too closed to the mobile. This noise will disappear when they are away from each other.

##### 2. Alarm issue.

Q: Why can not receive alarm message through E-mail?

A: Ensure your email detects it as a spam.

##### 3.Recording issues.

Q: What if the device is not able to record, or loop recording?

A: Formatting SD card through APP or PC, and insert SD card.If the record indicator light is not on, it means SD card is damaged.Change a new SD card. Remark: Insert or take out SD card after you cut off the power

Q: Can I download recording of SD card to your phone or computer?

A: Temporarily not support this feature.It is under development, please wait for the new version of the app.

##### 4. PC issues.

Q: Can I use the PC to watch the monitor screen?

A: Yes, you can download tool CMS through WWW.ihomeapp.cn

5.Q:What are the account and password of PC's program?

A: local login Account name: admin Password(do not need to type in) Account name(the account which you use in APP) Password:(same as the password in the APP)

Q: Is it available to view recording video in SD card through PC?

A: Yes,it is available through remote login.You can also download to local PC.

##### 6: Other Questions:

Can we login different devices within same account? For example, i have two mobiles. Can i use same account to log-in?

A: No, please register a new account

Q: What if I forget the password of device?

A:Long press RESET button to reset the device.The default password is 123456

Q: Night vision is bad?

A:Please follow the light to install the device and remove any reflective obstructions from the device.

#### 10.FCC warning statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the **FCC** Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Contact Us:[US.IPC@WONNIE.CO.UK](mailto:US.IPC@WONNIE.CO.UK)