



Follow us on Facebook

ARMOR MINI 4


Quick Guide



① Receiver	⑥ 3.5mm Headphone Jack
② 2.8-inch QVGA Screen	⑦ Flash
③ OK Key	⑧ 2MP Camera
④ Microphone	⑨ Speaker
⑤ Type-C Port	⑩ Screw

Instructions:

1. Press "↔" to check the call records or answer calls;
2. Press "↔" to reject the call or lock/unlock the screen;
3. Long press "●" to turn ON/OFF the flash;
4. Long Press "#" to change Normal/Silent/Meeting (Vibration) mode;







Power Adapter



USB Cable

Please Follow These Steps to Open the Back Cover

Step 1: Use the screwdriver which is packed in the package box to counterclockwise loosen the screw on the back cover;
Step 2: Remove the back cover;
Step 3: Insert the SIM card 1 & SIM card 2;
Step 4: Insert the TF card;
Step 5: Put the battery;
Step 6: Place the back cover in correct place and use the screwdriver to clockwise tighten the screw on the back cover.



Insert the cards

Slot 1/2: Standard Size SIM Card

Slot 3: TF Card



Note:

- 1) Do not use a hand-cut card or wrong type card in case of card slot getting damaged.
- 2) TF card is up to 64GB.

Network Bands:

GSM: B2/3/8 WCDMA: B1/8

FDD-LTE: B1/3/7/8/20/28A/28B

WARNING:

If you want to make a waterproof test, please tightly plug the stoppers of the SIM card slot and audio jack. After the test, please dry off the phone and make sure it is completely dry before turning on; otherwise, it may cause speaker noises! And if the phone was broken or after destructive test, please don't make the waterproof test.

CE Warning

1. Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.

2. CAUTION:
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

3. The product shall only be connected to a USB interface of version USB2.0.

4. Adapter shall be installed near the equipment and shall be easily accessible.

5. Operation temperature:-10~40°C

6. The plug considered as disconnect device of adapter.

7. SAR:

The device complies with RF specifications when the device used at 5mm from your body (SAR limit 2.0W/Kg), The device is in compliance with the requirements.



This information has to be presented in such a way that the user can readily understand it. Typically, this will necessitate translation into every local language (required by national consumer laws) of the markets where the equipment is intended to be sold. Illustrations, pictograms and using international abbreviations for country names may help reduce the need for translation.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

SAR tests are conducted using standard operating positions according to standards with the device transmitting at its highest certified power level in all tested frequency bands although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This model product has been tested and meets the RF exposure guidelines with the test distance 0mm for head and 10mm for body worn. The highest SAR1g value is 0.360 W/Kg for head and 0.679 W/Kg for body worn. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with RF exposure requirements, and should be avoided.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Regulatory Certification: If you need to view your device's certification number, follow these steps: Settings > About Phone > Regulatory Certification.

ulefone ®
All Rights Reserved

The information contained herein is subject to change without notice. The only warranties for Ulefone products and services are set forth in the express warranty statements accompanying such products and services.

Nothing herein should be construed as constituting an additional warranty. Ulefone shall not be liable for technical or editorial errors or omissions contained herein.

Shenzhen Gotron Electronic CO., LTD.

Address: Floor 7, Building A, Block 1, Anhongji Tiansao Plaza, Longhua District, Shenzhen City, Guangdong Province China

Service Center

Email : service@ulefone.com

